



**Web-Tech Australia Pty Ltd**

## **Model WT735 Weighfeeder**

### **Installation, Operation & Maintenance Manual**

**Web-Tech Australia Pty Ltd**

PO Box 4006

11 Electronics St

Eight Mile Plains QLD 4113

Ph: 61 7 3841 2844

Fax: 61 7 3841 0005

e-mail: [webtech@bigpond.com](mailto:webtech@bigpond.com)



# Web-Tech Australia Pty Ltd

## TABLE OF CONTENTS

Section	Description
1.	Introduction.
2.	Delivery & Unpacking.
3.	Mechanical Installation.
4.	Electrical Installation
5.	Weighfeeder Electronics
6.	Calibration
7.	Gearmotor Manual
8.	Variable Speed Drive Manual (if applicable)
9.	Drawings
10.	Calibration Sheets/Addendums

<b>A</b>	<b>1/12/04</b>	<b>Issued for reference.</b>	<b>L.H.</b>
Rev.	Date	Details	By

---

## SECTION 1 - INTRODUCTION

---

The Web-Tech model WT735 weighfeeders consist of a range of light to medium duty weighfeeders capable of handling various products. The model number extension eg. "300" denotes the belt width. Therefore a 735-300 is a model 735 with a belt width of 300mm. Web-Tech has selected a belt width based on the operating parameters supplied to us. Standard belt widths are 300mm and 600mm.

**PLEASE READ ALL SECTIONS OF THE MANUAL BEFORE PLACING THE WEIGHFEEDER INTO SERVICE.**

The model WT735 is available in either "open" or "enclosed" construction. Apart from the enclosure, the mechanical aspects are generally the same for both types. The only difference between the open and enclosed models is that the open construction uses a shaft mount gearmotor, and the enclosed models use a foot mount gearmotor with chain and sprockets. For open construction models, the weighfeeder may be supplied with an inlet chute with flange connection, or, with a "horseshoe" type inlet which consists of side and rear skirts. Enclosed construction models are supplied with internal inlet chutes. The inlet chute flange may be bolted directly to the outlet of a bin, however it is not designed to support any loads. This may happen for example if the bin is supported by a structure that can deflect when fully loaded. If this is the case a flexible connection should be used.

The weighfeeder dimensional layout and capacity have been determined by information supplied to Web-Tech at the product enquiry stage. Some 735 weighfeeders may change in overall dimensions and/or supply of ancillaries to suit the operational requirements. Should your weighfeeder vary from the standard design, an addendum will have been inserted in this manual to reflect the changes.

If there are any questions regarding any aspect of the weighfeeder design or installation, please do not hesitate in contacting Web-Tech for clarification **before** placing the weighfeeder into operation. The weighfeeder is generally programmed and calibrated in our factory prior to dispatch, however the weighfeeder will need to have the calibration re-checked after installation. The calibration sheets are located at the rear of this manual.

---

## SECTION 2 – DELIVERY & UNPACKING

---

Your weighfeeder has been crated for protection during transit. The weighfeeder electronics is normally packed separately in secure cardboard packaging. Upon delivery, please inspect all packaging for signs of damage. Report any damage to both the transport company and Web-Tech.

**PLEASE READ ALL SECTIONS OF THE MANUAL BEFORE PLACING THE WEIGHFEEDER INTO SERVICE.**

### **The basic components are:**

- Assembled weighfeeder c/w gearmotor, load cell(s) and belt speed sensor.
- Masterweigh/Optimus electronics.
- Calibration chain/weights.

### **Optional:**

- Variable Speed Controller.
- Remote Instruments.
- Spare Parts.

If in any doubt regarding any aspect of the delivery, contact:

Web-Tech Australia Pty Ltd  
Ph: 61 7 3841 2844  
Fax: 61 7 3841 0005  
Email: [webtech@bigpond.com](mailto:webtech@bigpond.com)

### **UNPACKING**

1. Carefully open the crate.
2. The weighfeeder is held in place by bolts in the mounting feet.
3. Remove the bolts and lift the weighfeeder clear of the crate using web slings – **NOT CHAINS**.
4. Ensure no parts have come loose during transit.
5. Carefully transport the weighfeeder to point of installation.
6. Open the cardboard box containing the electronics. Remove the electronics and check box for any remaining items.
7. Check electronics enclosure for any obvious damage.
8. Proceed to Mechanical and Electrical installation sections.



---

## SECTION 3 – MECHANICAL INSTALLATION

---

Refer to the general arrangement drawing at the rear of the manual.

### OPEN CONSTRUCTION WITH INLET CHUTE MODEL

The following is a summary of works required for the mechanical installation of an “open” construction model WT735 weighfeeder which is supplied with an inlet chute.

1. For high vibration areas the weighfeeder will be supplied with isolation blocks (loose supply). Locate these blocks and bolt them to the weighfeeder support feet.
2. Cover the weighfeeder if any metal cutting is to be performed. If any welding is to be carried out, remove the load cell from the weighfeeder.
3. Locate the weighfeeder on the support structure ensuring correct alignment. The structure must be sufficiently rigid to eliminate any deflection due to the weight of the weighfeeder and the product it's transporting.
4. Level the weighfeeder by placing a spirit level across and along the weighfeeder belt/structure. Any vertical alignment should be compensated for by using shim material under the support structure or weighfeeder isolation blocks/mounting feet. **DO NOT “PULL UP” ANY GAPS BY USING THE MOUNTING BOLTS AS THIS MAY TWIST THE WEIGHFEEDER FRAME.** The weighfeeder should be level in both directions to  $\pm 1^{\circ}$ .
5. If the weighfeeder is to be bolted directly to an overhead bin, a flexible gasket should be used between the bin and weighfeeder flanges. The thickness of the gasket should be sufficient to take-up and variation in gap that may exist between the two flanges.
6. Carefully tighten the flange bolts so that the gasket is compressed and the gap is completely closed. **DO NOT OVERTIGHTEN THE CONNECTION BOLTS SO THAT THE FLANGE IS BENT.**
7. If a flexible connection is to be used, ensure that any excess in the flexible material does not create a ledge, or restrict the flow of material from the outlet of the bin.
8. Locate and remove the gravity take-up transit bolt. The transit bolt head will have been painted red for easy identification. Refer to drawing “WT735-021” for location. Carefully lower the gravity take-up roll down onto the return belt.
9. Refer to drawing “WT735-031”. This drawing will show that the load cell is fitted with an overload bolt. This bolt has been factory set and should not be altered. On the bolt there is a red transit nut. During transit, this nut should be tightened upwards against the bottom of the load cell. Before operation this nut should be lowered to the bottom of the overload bolt as shown on the drawing. **MAKE SURE THAT THE OVERLOAD BOLT IS NOT MOVED WHEN ADJUSTING THE TRANSIT NUT.**
10. Before placing into operation, the alignment of the weigh bar should be checked. Referring to drawing “WT735-031”, locate the weigh bar position. Place a straight edge along each edge of the carry bars and check the height of the weigh bar. The weigh bar should with respect to the approach and retreat bars to a tolerance of  $+0.25\text{mm}/-0.00\text{mm}$ . If the weigh bar requires adjustment, remove the plastic plug in the end of the weigh bar and adjust the grub screw. When finished replace the plastic plugs.
11. The mechanical installation is now complete; proceed to the electrical installation section.

### OPEN CONSTRUCTION WITH “HORSESHOE” INLET MODEL

The following is a summary of works required for the mechanical installation of an “open” construction model WT735 weighfeeder which is supplied with a “horseshoe” inlet.

---

## SECTION 3 – MECHANICAL INSTALLATION

---

1. For high vibration areas the weighfeeder will be supplied with isolation blocks (loose supply). Locate these blocks and bolt them to the weighfeeder support feet.
2. Cover the weighfeeder if any metal cutting is to be performed. If any welding is to be carried out, remove the load cell from the weighfeeder.
3. Locate the weighfeeder on the support structure ensuring correct alignment. The structure must be sufficiently rigid to eliminate any deflection due to the weight of the weighfeeder and the product it's transporting.
4. Level the weighfeeder by placing a spirit level across and along the weighfeeder belt/structure. Any vertical alignment should be compensated for by using shim material under the support structure or weighfeeder isolation blocks/mounting feet. **DO NOT "PULL UP" ANY GAPS BY USING THE MOUNTING BOLTS AS THIS MAY TWIST THE WEIGHFEEDER FRAME.** The weighfeeder should be level in both directions to  $\pm 1^0$ .
5. The use of the "horseshoe" style inlet allows for a chute, metering tube or a pre-feeder such as a vibratory feeder to be used. If using a chute or metering tube, ensure that the bottom of the chute/metering tube does not interfere with the belt.
6. If the bottom of the chute/metering tube is fitted with skirts, ensure that excessive load is not placed on the belt. The skirts should just be in contact with the belt.
7. If the weighfeeder is to be supplied with a pre-feeding device such as a vibratory feeder, ensure that material is not deposited too far along the weighfeeder so that it is deposited on the weigh area (refer to the drawing for location of the product limits).
8. Locate and remove the gravity take-up transit bolt. The transit bolt head will have been painted red for easy identification. Refer to drawing "WT735-021" or location. Carefully lower the gravity take-up roll down onto the return belt.
9. Refer to drawing "WT735-031". This drawing will show that the load cell is fitted with an overload bolt. This bolt has been factory set and should not be altered. On the bolt there is a red transit nut. During transit, this nut should be tightened upwards against the bottom of the load cell. Before operation this nut should be lowered to the bottom of the overload bolts as shown on the drawing. **MAKE SURE THAT THE OVERLOAD BOLT IS NOT MOVED WHEN ADJUSTING THE TRANSIT NUT.**
10. Before placing into operation, the alignment of the weigh bar should be checked. Referring to drawing "WT735-031", locate the weigh bar position. Place a straight edge along each edge of the carry bars and check the height of the weigh bar. The weigh bar should with respect to the approach and retreat bars to a tolerance of  $+0.25\text{mm}/-0.00\text{mm}$ . If the weigh bar requires adjustment, remove the plastic plug in the end of the weigh bar and adjust the grub screw. When finished replace the plastic plugs.
11. The mechanical installation is now complete; proceed to the electrical installation section.

### ENCLOSED CONSTRUCTION MODEL

The following is a summary of works required for the mechanical installation of an "enclosed" construction model WT735 weighfeeder which is supplied with an internal inlet chute.

1. For high vibration areas the weighfeeder will be supplied with isolation blocks (loose supply). Locate these blocks and bolt them to the weighfeeder support feet.
2. Cover the weighfeeder if any metal cutting is to be performed. If any welding is to be carried out, remove the load cell from the weighfeeder.
3. Remove the side covers from the weighfeeder.
4. Locate the weighfeeder on the support structure ensuring correct alignment. The structure must be sufficiently rigid to eliminate any deflection due to the weight of the weighfeeder and the product it's transporting.
5. Level the weighfeeder by placing a spirit level across and along the weighfeeder belt/structure. Any vertical alignment should be compensated for by using shim

---

## SECTION 3 – MECHANICAL INSTALLATION

---

material under the support structure or weighfeeder isolation blocks/mounting feet. **DO NOT “PULL UP” ANY GAPS BY USING THE MOUNTING BOLTS AS THIS MAY TWIST THE WEIGHFEEDER FRAME.** The weighfeeder should be level in both directions to  $\pm 1^0$ .

6. If the weighfeeder is to be bolted directly to an overhead bin, a flexible gasket should be used between the bin and weighfeeder flanges. The thickness of the gasket should be sufficient to take-up and variation in gap that may exist between the two flanges.
7. Carefully tighten the flange bolts so that the gasket is compressed and the gap is completely closed. **DO NOT OVERTIGHTEN THE CONNECTION BOLTS SO THAT THE FLANGE IS BENT.**
8. If a flexible connection is to be used, ensure that any excess in the flexible material does not create a ledge, or restrict the flow of material from the outlet of the bin.
9. Connect the outlet of the weighfeeder using the same method i.e. use a flexible gasket.
10. Locate and remove the gravity take-up transit bolt. The transit bolt head will have been painted red for easy identification. Refer to drawing “WT735-02” or location. Carefully lower the gravity take-up roll down onto the return belt.
11. Refer to drawing “WT735-03”. This drawing will show that the load cell is fitted with an overload bolt. The bolt has been factory set and should not be altered. On the bolt there is a red transit nut. During transit, this nut should be tightened upwards against the bottom of the load cell. Before operation this nut should be lowered to the bottom of the overload bolt as shown on the drawing. **MAKE SURE THAT THE OVERLOAD BOLT IS NOT MOVED WHEN ADJUSTING THE TRANSIT NUT.**
12. Before placing into operation, the alignment of the weigh bar should be checked. Referring to drawing “WT735-03”, locate the weigh bar position. Place a straight edge along each edge of the

weigh bar and check the height of the weigh bar. The weigh bar should with respect to the approach and retreat bars to a tolerance of +0.25mm/-0.00mm. If the weigh bar requires adjustment, remove the plastic plug in the end of the weigh bar and adjust the grub screw. When finished replace the plastic plugs.

13. The mechanical installation is now complete; proceed to the electrical installation section.

---

## SECTION 4 – ELECTRICAL INSTALLATION

---

Electrical connection diagrams for the weighfeeder electronics, load cell and belt speed sensor junction boxes are located in the drawing section of this manual. Electrical connection diagrams for the gearmotor and variable speed drive (if applicable) are located in the appropriate manufacturer's manuals. Electrical installation comprises the following work:

1. Install and connect weighfeeder electronics to mains supply.
2. Install and connect supply to weighfeeder motor (or via VSD if supplied).
3. Install and connect cable between load cell junction box and electronics.
4. Install and connect cable between belt speed sensor junction box and electronics.
5. Install and connect cable between weighfeeder electronics and variable speed drive (if supplied).
6. Install cable between weighfeeder electronics and PLC (if required).
7. Install earth strap to weighfeeder structure (refer G.A. drawing for location). The weighfeeder structure should be earthed to eliminate static build-up from the structure.

### WEIGHFEEDER ELECTRONICS

The weighfeeder may be supplied with either of the following electronics models:

- "Masterweigh 1"
- "Masterweigh 5"
- "Optimus"

The appropriate electrical connection drawing or the electronics supplied is located in the drawings section of the manual.

### Enclosure Mounting

The electronics enclosure is an IP66 reinforced fibre polyester enclosure, or optionally an IP66 stainless steel enclosure. The enclosure should be located so that:

1. Is not in direct sunlight (install sunshield if located outdoors).
2. Is not subject to direct washdown.

3. Is not installed in close proximity to high power cables, variable speed drives or vibratory feeder controllers.
4. Not more than 100 metres from the weighfeeder. The closer the electronics can be located to the weighfeeder reduces the chances of electrical interference on the cables. It also makes it easier when carrying out calibrations and fault finding.

### Cables

All cables between the load cell/belt speed sensor junction boxes and the electronics should be proper screened instrumentation quality. As the signal levels from these devices are very low, any cable runs between the weighfeeder and electronics should be carried out so that these cables are not installed close to power cables. Any cable runs should not interfere with the "access" side of the weighfeeder which may interfere with belt removal.

Suggested cable type for each application is as follows:

**Load Cell** – 4 core overall screened, Belden type 8723 or equivalent.

**Belt Speed Sensor** – 3 core overall screened, Belden type 8723 or equivalent.

**VSD/Motor** – To suit the motor power installed.

Ensure that all cable entries into the electronics enclosure and junction boxes use the correct size waterproof glands.

### Cable Terminations

**Load Cell junction box** – Refer to drawing "LCJB" in the drawing section of the manual.

**Speed sensor junction box** – Refer to drawing "SSJBOX" in the drawing section of the manual.

As the model WT1200 weighfeeder is supplied with a variety of motor/VSD

---

## SECTION 4 – ELECTRICAL INSTALLATION

---

combinations, it is beyond the scope of this manual to give installation/connection here. Please refer to the manufacturer's manuals in other sections of the manual.

existing value. It should be within  $\pm 1\text{Hz}$ .

If all readings appear correct, proceed to the Calibration section of the manual.

### START UP

Prior to turning on the equipment, or starting the weighfeeder, ensure the following has been done:

1. Double check all electrical connections are correct.
2. All mechanical installation has been completed and no tools have been left on the belt or in the inlet chute.
3. The rotation of the motor has been checked and wired correctly.

### Start Up Steps

When starting up the system for the first time, use the following steps.

1. Turn on the electronics, and ensure it displays the Mass Rate, Mass Total (MRMT).
2. Start the weighfeeder. If using variable speed drive, set it in local and ramp the frequency up to 50Hz.
3. Ensure the belt is tracking centrally. If the belt is not tracking centrally, turn the weighfeeder off and check that the belt is sitting correctly in the guides on the tracking system.
4. The load cell output can be directly read from the electronics. Refer to the electronics manual for the appropriate menu for reading the load cell voltage. Refer to the calibration sheets at the rear of the manual and compare the factory programmed voltage (mV) to the existing value. It should be within  $\pm 0.5\text{mV}$ .
5. The belt speed sensor output can be read directly from the electronics. Refer to the electronics manual for the appropriate menu for reading the belt speed sensor frequency output. Run the weighfeeder, refer to the calibration sheets at the rear of the manual and compare the factory programmed frequency (Hz) to the

# KEYBOARD AND LAYOUT FUNCTIONS

## KEYBOARD LAYOUT

1	2	3	4
5	6	7	8
9	0	C	MENU
-	./+	ABORT A	ENTER E

**Masterweigh 1 can operate in a protected security or open mode depending on the initial security configuration.** See "Security" for set up details. The following text assumes that the operator has gained access to the system.

## SECURITY CODES

If Masterweigh 1 has been ordered with the security pass system activated, entry to the menus will be restricted. (Two four-digit codes will have been supplied to nominated persons in your company).

One code (low level) allows the code holder limited access to any data in the menus, for inspection only. The other code (high level) is needed for access to menus and to make modifications to constants, start calibration sequences, etc. Note that no access is given if no code is entered.

If security codes have been activated, on pressing the Menu key, the computer waits for the four-digit code. If no attempt is made to enter a code then the display returns to MRMT format after 30 seconds. If an invalid code is detected, the display returns to MRMT format immediately. If a security code is detected then limited or complete access is gained to the menus, as appropriate. Once the menu format is exited the code will have to be re-entered for further access.

## KEY FUNCTIONS

### Menu

This key switches between the main display mode showing "Mass Rate/Mass Total" (MRMT) and the "Menu" mode.

### (-) and (./+)

When in "Menu" mode, pressing the (+) or (-) key once will go forward or backward one menu entry. If either key is held down, the menu changes will repeat at a rate of approx. 5 per second. When entering data, the (./+) key is the decimal point.

### A/Abort

When in the "Menu" mode and entering changes or new data, this key enables the user to abort the changes and restore the existing entries. The top level menu screen is then displayed.

### C/Cancel

Similar to "Abort", except that the current screen data only is cancelled and the existing entries restored. The display remains at the current screen.

### E/Enter

In menu mode, the key accepts the default setting or confirms any data entered and moves to the next level in the operating sequence.

In MRMT display mode, if the "Enter" key is pressed, the current CPU (central processor unit) status is displayed and also the number of times the CPU has been restarted.

If the display is flashing, the CPU fault status may be viewed by pressing the enter key in the MRMT display mode.

## MENU ENTRY 1 – Parameter Setup

The setup menu is used for initial setup of the Masterweigh, for examination of these parameters whenever desired and during periodic recalibrations.

1

Menu entry: 1 Parameter setup
----------------------------------

2

Current Capacity = 1000.000tonnes/hour Enter new capacity ? 0.00
---

3

Mass total increment = 1.000 tonnes Enter new inc. (1 - 0.001) ? 0.000
---

4

WARNING: Factory preset data following, Do Not Modify - Press A to continue
--

5

Calibration zero = 4.365 milli-volts Enter new zero ref. ? 0.000
---

6

Precision ref. = 34.315 millivolts Enter new precision ref. ? 0.000
--

7

Current pulse width = 300m/s 1 = 100, 2 = 200, 3 = 300
---

1. At Menu Entry 1, press Enter to examine or modify these parameters.

2. The current weigh capacity is displayed. A new value may be keyed-in. Then press Enter to continue. Otherwise press Enter with no data entry to retain existing values and continue. This value sets the 100% point for the 4-20mA mass rate output signal. Note that

the system can measure mass rates above this value (assuming the instruments remain within their normal operating range), and higher values will be shown on the screen and totalised. However, the 4-20mA mass rate output signal will show 20mA for all mass rates above this value.

Note that units can be changed to tons, lbs or kg if preferred, within Menu Entry 18.

3. This entry displays and allows alteration to the mass total increment. This increment is used for both the mass rate and the mass total displays.

Enter the new value required and press the Enter key. No change is made if Enter is pressed without data entry.

Note that the increment set is the increment required to cause one pulse output from the electronic counter. Also, do not change the increment in normal operation, as the change in setting will invalidate any existing accumulated mass total.

4. A warning message now appears, since the following adjustments are NOT normally altered by the user.

5. During initial setup and periodic recalibration, zero reference and precision reference millivolt figures must be entered. The data is keyed in and Enter pressed to save the values. The values shown here should be the same as those engraved on to the main board. If no data is entered but the enter key is pressed then no data change is made.

6. See 5 above.

## MENU ENTRY 1 – Parameter Setup

---

7. This step displays and allow alteration to the remote counter pulse width. This value is limited to the values shown. Pressing one of the numeric keys on the keypad that corresponds to the values shown will set that value as the pulse width. One pulse is output each time the mass total increases by one increment ( as set in step 3 above ).

Enter a pulse width that will match with the remote counter response time, but keep the following in consideration when selecting this value : The pulse output can go no faster than the value you just selected, but the accumulation of the mass total may, and so the remote totaliser will fall behind the actual mass total. E.g. if the pulse width is set to 100mS, then at it's fastest rate, the output will be on for 100ms, then off for 100ms. This will give a maximum output of 5 complete pulses per second ( 100mS on and 100mS off = 200mS per total pulse ). Therefore, if the feeder is running faster than 5 increments per second ( = 18000 increments per hour ), then the remote total will be wrong. E.g for an increment value of 0.01tonnes, the limit will be 180tph.



## MENU ENTRY 2 – Pulses per Belt Revolution Calibration

This calibration is carried out with the belt moving. The number of complete belt revolutions over a time period are counted by the operator, and the Masterweigh counts the pulses returned from the speed sensor device. The revolutions are then entered using the keypad and the pulses/rev calculated by the Masterweigh and then saved.

To enable the revolutions to be counted, a point on the belt should be marked with paint, and a suitable point on the framework chosen close to the belt. The count is then started as the belt mark passes this point and stopped as the mark again passes this point after the greater of 5 minutes or 5 belt revolutions.

1

Menu entry: 2
Pulse per rev = 1000 Revs =5

2

Manual entry of Pulses/Rev or press Enter to continue
--

3

Manual entry of N. of Revs or press enter to continue
--

4

To start belt pulse count, Press E
Pulse counted = Time =

5

To stop belt pulse count, Press E
Pulses counted = Time =

6

Enter number of belt revolutions ?
Pulses counted = Time =

7

Pulses per belt revolution = Press E to save, otherwise press A
--

1. At Menu Entry 2, press Enter to proceed with calibration.
2. If the pulses per rev are known, then manually key in the number of pulses and press E. Otherwise simply press E to continue.
3. Manually key in the number of revs (for the above number of pulses) and press E. Otherwise press E to continue.
4. At the moment the belt mark passes the fixed point chosen, press E to start the Masterweigh counting pulses, and start counting revolutions. Note that the display panel will show the counting.
5. After at least 5 minutes, press E again to stop the count as the mark passes the fixed point.
6. Key in the number of revolutions counted, and press E to confirm.
7. Press E to save the number of pulses/rev just calibrated, otherwise press A to abort and return to the original values (if any).

## MENU ENTRY 3 – Load Zero Calibration

This menu entry enables the operating zero to be calibrated. A specified number of belt revolutions are run (as determined by Menu 2), with no material or calibration weights on the belt. If the zero is correct then the mass total accumulated over the period will be zero.

The display shows the currently stored value in millivolts, as read at the load-cell input including any contribution made by the autozero function.

Note that the zero value is automatically adjusted if the excitation voltage changes.

1

Menu entry: 3 Zero cal. = 2.563mV      2.563mV ZTrck
---

2

Manual entry of Zero Error,      0.000mV or press Enter to continue
--

3

Press E to continue Mass rate = 0.000
--

4

(Zero reset) To Start zero cal, Press E Mass rate = 0.000    Revs =    0.0
---

5

To Abort zero calibration, Press A Mass rate = 0.000    Revs =    0.0
--

6

To calculate new calibration, Press E Mass total =    1.150    Revs =    10
--

7

Zero error =    2.756 millivolts Press E to save, otherwise press A
--

1. At Menu Entry 3, press Enter to proceed.

2. ( Optional ) Using a digital voltmeter, measure the belt zero error value (in millivolts) at the loadcell, or read the mV level displayed in menu 8.

Manually key in the value to the Masterweigh and press the Enter key to accept. Otherwise, press Enter with no data entered to continue with no change.

Note that entering this value does not negate the need to perform a zero calibration.

3. The live zero error is now displayed as a mass rate. Press Enter for the loadcell calibration procedure.

4. The mass total will now display zero. Check that the belt is empty, then press the Enter key to begin the zero calibration test.

5. The difference between the current loadcell zero and the actual load reading is accumulated over the test duration, which is the total number of belt revolutions specified in menu 2.

The test can be aborted at any time by pressing the Abort key. If the test is aborted, the "working copy" of the load zero is reinitialised from the stored load zero calibration value. This "working copy" normally includes contributions from both the load zero calibration (as carried out in this menu entry) and the auto zero tracking function. It is thus possible by entering the menu to this level and then aborting to reinitialise the working copy of the load zero and remove any auto zero tracking contribution.

## **MENU ENTRY 3 – Load Zero Calibration (Cont'd)**

---

6. This display will come up automatically when the belt has completed the required number of revolutions. The measuring phase of the test has finished and the resulting mass total is displayed. This mass total should be approximately zero, however if non-zero then a new loadcell zero may be required.

Press the Enter key to display the millivolt offset resulting from this test.

7. The new loadcell zero, or offset, is displayed in millivolts. Press the Enter key to save this value as the new loadcell zero, or press Abort to exit without saving.

## MENU ENTRY 4 – Fixed Weight Calibration

This menu entry allows the automatic calibration of the load-cell span. The test is run over a preset number of belt revolutions, as set in Menu 2, during which calibration weights (or weigh chains) are placed on the belt or weighframe. A mass total is accumulated in the course of the test. This total is then compared with an expected or "target" weight and the span adjusted accordingly. A load zero calibration should generally be performed (Menu 3) before running this procedure. The display shows the currently stored loadcell span value.

1

Menu entry : 4 Fixed weight calibrate, span = 222.1
--

2

Manual entry of Span Factor, 0.000 or press Enter to continue
--

3

Target Weight = 120.8 tonnes Enter target weight ? 0.000 tonnes
--

4

Press E to continue Mass rate = 0.000
--

5

To Start span calibration, Press E Mass rate = 0.000 Revs = 0.0
--

6

To Abort span calibration, Press A Mass rate = 1543.00 Revs=2
--

7

To calculate new calibration, Press E Mass total = 120.000 Revs = 10
---

8

New span factor = 223.580 Press E to save, otherwise press A
---

9 (Seen only if span invalid)

Span of 345678.123 is invalid Press A to continue
--

1. Press Enter when at Menu Entry 4 to proceed.

2. At this stage the belt span factor can be set manually by entering the desired span factor and pressing the Enter key. If no value has been entered, then no change is made to the stored value and the next level is entered.

3. The target weight is the mass total that is expected over the number of belt revolutions as currently set (Menu 2) when the calibration weights are in place and hence are simulating a load on the weigh frame. This target weight may at this point be changed to suit the calibration weights being used. Note that this value will generally be determined by running this procedure and recording the result, immediately after performing an empirical calibration. (Menu 5).

If a new value is entered then pressing the Enter key will save this as the new target weight. If the Enter key is pressed without entering a target weight, then no change to the stored value occurs.

4. The current mass rate is shown, the number of belt revolutions is zeroed. Press the Enter key to start the test.

5. Once started the test will run until the currently specified number of belt revolutions has been counted. (Refer Menu 2).

6. During this step the weight is totalised over the specified number of belt revolutions, after which time the totalisation is automatically stopped. If the Enter key is pressed during the test, then the totalisation will be terminated, with a mass total of zero. The test can be aborted at any time by pressing the Abort key.

## **MENU ENTRY 4 – Fixed Weight Calibration (Cont'd)**

---

7. The resulting mass total is displayed along with the number of belt revolutions counted. Press the Enter key to calculate the new span calibration factor.

8. The new derived load-cell span is displayed. Press the Enter key to save this value as the new loadcell span. Press the Abort key if this value is not to be stored, and the previous span value will be used for the span.

9. Should the span value calculated be outside the range 0.1 to 3000 then the Masterweigh will display a warning message. Under these circumstances the new span will not be saved, and the unit will revert to the value previously stored.

## MENU ENTRY 5 – Empirical Span Calibration

This menu entry enables the entry of manual belt totalisations and the resultant re-calculation of the loadcell span. To use this calibration facility, it is necessary to weigh a quantity of material with the belt scale and then to accurately determine the actual mass of that material by independent means (ie. via a weighbridge). The two totals are then entered and the Masterweigh computes the new span factor.

1

Menu entry : 5 Empirical calibration, span = 211.7
---

2

Enter weigh bridge total ? 0.000
----------------------------------

3

Enter belt scale total ? 0.000
--------------------------------

4

New span = 205.6, Previous=211.7 Press E to save, otherwise press A
--

1. At Menu Entry 5, press Enter to proceed.
2. Enter the exact mass total, as measured by the weighbridge or other accurate method. Press Enter when the data is correct.
3. Enter the mass total as measured by this Masterweigh unit. Press Enter.
4. Press Enter to store the new span value as the loadcell span calibration factor. Press Abort if no update is required.

## MENU ENTRY 6 - Null Level

This entry displays the level at which the load is considered to be zero. Below this level, the mass rate display will show zero, no increment of the mass total will occur, no pulses will be output to the e.m. pulse counter and the mass rate analog output will be set to 4.0mA.

1

Menu entry : 6 Null level = 20.000 tonnes/hour
---

2

Enter a new null level ? 25 Mass rate = 22.657 tonnes/hour
---

1. At Menu Entry 6, press Enter to proceed.
2. Key in the new null level of zero. Press Enter when the data is correct.

Note on selecting the null level : This entry is used to mask variations in mass rate caused by variations in the belt weight, caused by the belt splice etc. To select the null level, observe the mass rate shown over several belt revolutions with the belt running completely empty ( i.e no product or calibration weights ). Take note of the highest equivalent mass rate reached, then enter a value slightly higher than this level. E.g. if the mass rate was swinging from -20 to 0 to +20 select 22 as the null level. On a correctly installed and aligned weigher, this figure should be approximately 1% of capacity.

## MENU ENTRY 7 – Auto Zero Tracking

This entry specifies the level below which automatic zero tracking occurs and the number of belt revolutions required before a new zero level is established in the Masterweigh.

The auto zero mode will not be entered, or continue unless the mass rate remains below the specified level. The value is normally set at approximately 1.5% of capacity. A qualifying time delay period is also provided to ensure that the belt is completely free of material.

Should it be necessary to clear the present auto zero value, then this can be done by entering Menu 3 (load zero calibration), then aborting after starting the test. A "z" will be displayed at the right hand side, bottom line, of the main mass rate/mass total display, when the auto zero conditions are met and the Masterweigh is collecting data for a possible new zero level. Note: The auto zero tracking procedure is inhibited under the following conditions:-

- Masterweigh not in the mass rate / mass total display mode

or

- Input tacho frequency less than 5.0Hz.

1

Menu entry : 7 Zero track if < 20.0 for 5 revs
---

2

Auto zero level = 20.000 tonnes/hour Enter new level ? 0.000
---

3

Auto zeroing period = 5 revs Enter new period ? 0
--

4

Delay before auto zeroing = 60 secs Enter new delay ? 0
--

1. At Menu Entry 7, press Enter to proceed.
2. Enter the new autozero level in mass rate units and press the Enter key. If the Enter key is pressed with no data entry then the stored value remains unchanged.
3. Enter the period required (in belt revolutions) over which autozeroing occurs. Note that the number of belt revolutions should be chosen such that the total zeroing period is of the order of 15 minutes or more. This will ensure that accurate zero levels are produced.  
  
Note that the actual zero level used by the Masterweigh will not be updated until a zeroing period has been completed. If a new value is entered and the Enter key is pressed then that value is saved, otherwise no update occurs.
4. This entry enables the qualifying delay time to be set. Choose a time that will ensure that all material is off the belt. The delay time commences when the mass rate falls below the minimum level set above.

---

## MENU ENTRY 8 – Loadcell Input

---

This entry displays the loadcell input in millivolts. The displayed value is unaffected by the load zero, load calibration, and zero tracking functions. In addition to the loadcell value, the entry displays the excitation voltage as currently sensed by the Masterweigh. It is displayed to the nearest volt only, i.e. 10V implies a voltage in the range 9.501 to 10.5V. The excitation value is updated once every 3 minutes. This display is provided to enable a user to confirm that the Masterweigh is correctly sensing the excitation voltage and thus that all links etc. are correctly installed. Incorrect excitation sensing will result in inaccurate and unstable mass rate measurements.

1

Menu entry : 8 Load cell = 16.235mV, (Exitn. = 10V)
--

1. This menu is for display only.

---

## MENU ENTRY 9 - Tacho Frequency

---

This entry displays the current tacho frequency in hertz, ( the input range is 5Hz to 1000Hz) and switches between software or hardware inputs.

1

Menu entry : 9 Tacho Frequency=50.005 Hertz
--

2

Tacho source = Hardware Press Clear to change, Enter to accept
---

3

Tacho source = Simulated Press Clear to change, Enter to accept
--

1. Press "E" to enter the menu to select the source of the tachometer signal.
2. Press "C" to change (or toggle) between the available pulse sources which are :
  - Hardware – input signal to the system as generated by the speed sensor ( magnetic pick-up or optical tachometer )
  - Simulated – an internally generated 100Hz signal that is always on.
3. Press "E" to accept and return to the Menu Entry 9.



---

## MENU ENTRY 10 – High Alarm Setpoint

---

This entry displays the level that must be exceeded by the mass rate, for the period specified, before a high alarm is generated. When the alarm is generated, the high alarm relay is energised. The alarm indication is cleared, the relay is de-energised, and the delay period reset as soon as the mass rate returns below the high alarm set point.

1

Menu entry : 10 High alarm = 800.000 Delay = 60 secs
---

2

High alarm level = 800.000 tonnes/hour Enter new level ? 0.000
---

3

Alarm delay = 60 secs Enter new delay ? 0
--

1. Press the Enter key at Menu Entry 10 to change the settings.

If no change is keyed in and the Enter key is pressed, the values are unchanged. If an alarm level of zero is entered, then the high alarm is disabled.

2. Enter the period required, in seconds, for the mass rate to exceed the high alarm level, before high alarm is generated.

Then press the Enter key. If no data is entered and the Enter key is pressed, then no change occurs to the stored delay.

---

## MENU ENTRY 11 – Low Alarm Setpoint

---

This entry specifies the level below which, and the delay that must be exceeded before a low alarm output is generated. When the alarm is generated, the low alarm relay is energised. The alarm indication is cleared, the relay is de-energised, and the delay period reset as soon as the mass rate returns above the low alarm set point.

1

Menu entry : 11 Low alarm = 100.000 Delay = 60 secs
--

2

Low alarm level = 100.000 tonnes/hour Enter new level ? 0.000
--

3

Alarm delay = 60 secs Enter new delay ? 0
--

1. Press the Enter key at Menu Entry 11 to change the settings.

2. If no change is keyed in and the Enter key is pressed, the values are unchanged. If an alarm level of zero is entered, then the alarm function is disabled.

3. Enter the delay (in seconds) required before a low alarm is generated, then press the Enter key. If no data is entered and the Enter key is pressed, then no change occurs to the stored data.

## MENU ENTRY 12 – Print Parameters List

The data to be printed is output via the RS232 serial data port, which is provided on the Masterweigh. The communication parameters are as follows:

Baud Rate 19.2kB      Stop Bits      1  
Data Bits    8              No Parity Check

1

Menu entry : 12  
Press E, to print parameter list

1. Press the Enter key at Menu Entry 11 to print the current stored values of the various weigh parameters.

Note that some versions of software have had this feature disabled. The menu will still be present, but pressing the Enter key will do nothing.

## MENU ENTRY 13 - Auto/Manual Control of MW PID Output

The current operating mode of the PID output, "Auto" or "Manual", is displayed at the bottom right corner of the display. Additionally, when the PID output is in manual mode an upper case "M" is displayed in the bottom right corner of the main "mass rate/mass total" menu.

1

Menu entry: 13  
PID O/P Auto/Manual      Mode = Auto

2

Rate = 286.47- S.P. = 300.0 O/P = 53%  
+/- controls O/P,      Enter to set mode

3

PID O/P Mode =      Auto  
Press Clear to change, Enter to accept

1. Press Enter key at Menu Entry 13. The current measured values of mass rate, PID setpoint and the manual mode PID output settings are displayed.

2. When operating in automatic mode, the PID output performs as previously, the output being based on the current mass rate, PID setpoint and PID constants. When operating in manual mode, the PID output is forced to the value

manual mode PID output can be increased or decreased by using the '+' or '-' keys. The keys increment/decrement the output by 0.5% respectively, to take advantage of the maximum analog output resolution of the Masterweigh. The +/- keys are auto repeating if held pressed for more than one second, to allow fast setting of the desired manual mode PID output value. The range of the manual mode PID output is automatically limited to values between 0 and 100% (4-20mA). Press the Enter key to move to the next level. Note that when manually entering PID values, the values can roll over. Eg. if the current value is 100% and the + key is pressed, the output will become 0%. If the current value is 0% and the - key is pressed, the output will become 100%.

3. Pressing the Clear key toggles the current PID output mode and the display will indicate any mode changes. Pressing the Enter key will accept the PID output mode currently displayed and return to Menu Entry 13.

displayed (for the manual mode PID output) as a percentage of 4-20mA. The value of the

## MENU ENTRY 14 – PID Parameters

The Masterweigh includes a proportional/Integral/Differential (PID) control loop for use in controlling mass flow rate. The PID variable for the controller is the current mass flow rate as displayed by the Masterweigh. The output from the controller is via a 4-20mA analog output (channel 2). The controller output is updated once per second, and would normally be used to control belt speed.

1

Menu entry : 14 PID parameters
--------------------------------

2

Current setpoint = 800.000 tonnes/hour Enter new value ? 0.000
---

3

Proportional term = 0.500 Enter new value ? 0.000
--

4

Integral term = 0.010 Enter new value ? 0.000
--

5

Integral lower limit = 0.000 Enter new value ? 0.000
---

6

Integral upper limit = 0.000 Enter new value ? 0.000
---

7

Differential term = 0.000 Enter new value ? 0.000
--

1. Press Enter at Menu Entry 14.

2. Enter a new set point in mass units if required. This value will only be used in the control algorithm if the setpoint mode is set to "Local" in Menu 15. Pressing Enter without typing new data will move the display to the next entry without altering the stored data.

3. Enter a new proportional gain term if required, or Enter only to leave data unchanged.

**NOTE:** The proportional term is "normalised" by the Masterweigh such that a gain of 1, an error of 100% full load capacity (as currently set in Menu 1), will cause a full scale (100%) out current.

4. Type in a new integral term, or Enter only to leave data unchanged.

**NOTE:** The integral term is "normalised" by the Masterweigh such that with an integral term of 0.01 and an error equal to the current capacity (as set in Menu 1), 1% will be added to the current output level each 0.5 second. (Or say 10% for an integral term of 0.1)

5. This entry allows the operator to prevent Masterweigh decrementing the integral term below a set value, thus preventing "wind-up".

6. This entry allows the operator to prevent Masterweigh incrementing the integral term above a set value, thus preventing "wind-up".

7. Enter a new differential term, or press Enter only to retain existing data. The differential (or derivative) term is normalised such that with a differential term of 1, a change in error equal to the current capacity in 1 second, will cause an instantaneous output of 100%.

---

## MENU ENTRY 14 – PID Parameters (Cont'd)

---

8

Output offset term = 0.500 Enter new value ? 0.000
---

8. Enter a new output offset term if required, or press Enter only to leave the current output unchanged.

9

Feed forward term = 0.000 Enter new value ? 0.000
--

**Note:** The output offset term is "normalised" by the Masterweigh such that, with an output offset term of 0.1, the normal PID controller output will have added to it a value equal to 10% of full-scale.

10

To zero accumulated Integral press E Else press A
--

9. The feed-forward control component operates by multiplying the set point value by the entered feed-forward term and adding the result onto the PID control algorithm calculated output value.

Feed-forward control has a beneficial effect on controller response time and stability when the process being controlled has a long time delay. The feed-forward term can be set to zero for control applications where it is not required. Enter the new value for the feed-forward term. If no value for the feed-forward term is entered, then no change is made to the currently stored value.

10. It may be desirable to zero an accumulated integral in the PID controller; for example, after the Masterweigh is left operating when the belt has been stationary for some time. At this stage pressing the Enter key will zero the accumulated integral. If abort is pressed instead, then the current accumulated integral will remain unchanged.

## MENU ENTRY 15 & 16 – Remote Setpoint

The Masterweigh can accept a feed rate setpoint from the keyboard or by reading the current flowing in an external 4 -20mA current loop. (Note: The setpoint can also be set from the RS232 communications port. This is easily achieved with the multi-drop Masterweigh network adaptors, which are an optional supply. Please contact Web-Tech if you require more information on the Masterweigh Network. )

The remote setpoint is in the form: -

4mA = 0 units 20mA = Masterweigh full scale belt capacity
--

If the remote signal is enabled, the input signal is converted to a mass rate using the above scaling characteristic and displayed in Menu 16.

In this way Menu Entries 15 and 16 follow the sequence below:

Menu Entry : 15 Remote Setpoint Mode = On
--

The remote setpoint will be displayed as "On" or "Off" depending on whether remote setpoint operation has been enabled or not.

Pressing "E" (Enter) will advance the display to:

Remote Setpoint Mode = On Press clear to change, Enter to ACCEPT
---

Pressing "C" (Clear) will toggle remote setpoint operation either "On" or "Off".

Pressing "E" will set the remote mode to that selected.

The display drops through on pressing "E" above with message:

WARNING: Calibration Data Do Not Modify - Press A to continue
--

If you do not wish to calibrate the current loop input, press "A". To calibrate the input, press "E". The following message will be displayed:

Remote Setpoint 4mA Press Clear to calculate new calibration
---

At this point, inject 4mA from an external device, i.e. simulator, PLC, etc.

Press "C"  
Display changes now read:

Remote Setpoint 20mA Press Clear to calculate new calibration
--

Inject 20mA from external source as above.

Press "C"  
The display will now revert back to Main Menu 15 heading displaying:

Remote Setpoint = ON
----------------------

Press Advance +/- key to Menu 16.

This menu displays the current value being used as the setpoint, and the setpoint mode. Eg. as below:

Menu Entry: 16 Setpoint = 1001.334 tonnes/hr.      Remote
--

## MENU ENTRY 17 – Modification of Filter Constants

Filtering can be applied to the following functions:

- Displayed mass rate
- 4-20mA mass rate output
- cascade controller output to PID controller ( ie. remote setpoint )
- mass rate output to PID controller
- PID controller output.

The level of filtering is specified by a constant which may be in the range 1 second to 120 seconds. Time constants greater than 120 seconds have the same effect as a 120 second constant. A time constant of 1 second is equivalent to no filtering. Time constants greater than 1 second introduce a delay in the rate of change of the filtered function.

1

Menu entry : 17	
To modify Filter factors press Enter	

2

Display Time constant is	2 secs
Enter new Time constant	0

3

Rate O/P Time constant is	4 secs
Enter new Time constant	0

4

Cascade Time constant is	4 secs
Enter new Time constant	0

5

PID I/P Time constant is	3 secs
Enter new Time constant	0

6

PID O/P Time constant is	4 secs
Enter new Time constant	0

1. Press Enter to modify the display filter time constant.

2. The display mass rate filter time constant is shown. When a time constant of greater than 1 is selected, the main mass rate display is damped. A new value for the display filter constant may be entered.

3. The 4-20mA mass rate output filter time constant is now displayed. A new value for the mass rate output filter constant may be entered.

4. The time constant for cascade control to PID input filter is displayed. A time constant of greater than 1 will cause the cascade input signal to be damped before being applied to the PID control algorithm. A new value for the Cascade filter constant may be entered.

5. The PID controller input filter time constant is displayed. A time constant of greater than 1 will cause the mass rate signal, which is fed back to the PID input, to be damped before it is applied to the PID control algorithm. A new value for the PID input filter constant may be entered.

6. The PID controller output filter time constant is displayed. A time constant of greater than 1 will cause the PID control algorithm output signal to be damped before it is output via the 4-20mA output. A new value for the PID output filter constants may be entered. Operation now returns to Menu Entry 17.

**Note: At each step, pressing the Enter key will save the new value. If a new value has not been entered, then the current value is unchanged.**

## MENU ENTRY 18 – Modification of Displayed Units

The displayed units for mass rate may be selected from tonnes/hour, lbs/hour, tons/hour, kgs/hour and kgs/minute. The displayed units for mass will be the same as those selected for mass, ie. tonnes, hour, hour or kgs.

1

Menu entry : 18 To modify displayed Units, Press E
---

2

1 = ton/hr	2 = lb/hr	3 = kg/hr
4 = tonne/hr	5 = kg/min	

1. Pressing the Enter key will advance to select mass units.

2. At this stage the mass rate units which can be displayed are shown.

To select the mass rate unit required press the number key associated with it, then press the Enter key.

The units number selected will be shown in the lower right hand corner of the display. Numbers greater than 5 will not change the currently displayed mass total and mass rate units.

Pressing the Enter key without entering a new unit number will not change the currently displayed units.

## MENU ENTRY 19 - Belt Speed Indication

This entry displays the current belt speed in metres/second ( or feet/minute if the mass rate unit is in tons or lbs ) based on the total belt length in metres.

1

Menu entry : 19 Belt speed = 3.10 metre/second
---

2

Current belt total length = 200.000 m Enter new belt total length 0.000 m
--

3

Enter measured belt speed in m/minute 0.000 Press E for belt length
--

4

Calculated belt length = 197.698 metres Press E to Save, otherwise press A
---

1. This entry shows the current calculated belt speed. Press Enter once to enter new total belt length in metres.

2. The current value for the belt length is shown. If the belt length is known, enter it here.

3. If the belt length is not known, and an accurate belt speed has been physically measured from the belt itself, the Masterweigh can calculate the belt length. Enter the measured belt speed in the units shown, then press E to calculate the new belt length.

4. If you entered a belt speed, this value will be the calculated belt length. If it seems correct, Press enter to save the value, or abort to ignore the calculation. Note that if you entered a belt length in step 3 and not a belt speed in step 4, this value will be meaningless. Press E to continue.

---

## MENU ENTRY 20 – Clearing Mass Total

---

Menu entry : 20  
Press C, to clear Mass Total

1. When the mass total on the "mass rate/mass total" display (MRMT) is to be zeroed, press C at Menu Entry 20. All totalised figures are then cancelled by the integrator.

Press Menu, then Enter to return to the MRMT display.



---

## RESETTING MASTERWEIGH

---

Under some circumstances Masterweigh's memory can be corrupted so that correct operation of the unit is not possible. This condition can occur if Masterweigh has been subjected to severe electrical noise or spikes.

These phenomena usually occur on 240/110V AC power lines, however they can also appear on the loadcell input cables as well as the tachometer cables. Masterweigh has been protected as far as possible, however, severe noise or spikes can get through.

Once any part of memory has been corrupted Masterweigh will detect it and automatically flag an error. If the corruption has only changed data, an error may not be detected and some erroneous results may occur. The only way to clear the memory of this data is by re-initialising.

Switching off and on will not clear the memory. The act of re-initialising causes all the calibration data to be lost and replaced by factory data. The calibration data specific to your application can easily be re-entered if you have kept a note of what was in the menus.

Menu 1 however, does have specific data which is logged on the main PCB under Calibration zero and Precision ref..

**LOG ALL CALIBRATION DATA, AS YOU MAY NEED TO MANUALLY RE-ENTER IT AT A LATER DATE.**

**TO RE-INITIALISE MASTERWEIGH PROCEED AS FOLLOWS:**

(For software versions 2.9 & over only)

1. Switch off Masterweigh.
2. Simultaneously press the Minus and Enter keys.
3. With both the above keys pressed switch Masterweigh on.
4. The display will now show the message:

Press C to Configure  
Any other key to continue

5. Now press the C key and Masterweigh will return to normal running mode.
6. To check that configure has been accepted, press E key. Display will read:

System normal - Reset = 3 (+ to clear)  
Configure = 2 (- to clear)

Note: Each time Masterweigh is powered up, reset figure increments one count. Configure number remains the same unless another configure is attempted, whereupon the count increases by one.

7. Press E key to return to running mode.
8. Values in all menu entries will now default to factory values.
9. Ensure precision zero and span voltages are entered in Menu 1 correctly before entering all other data values in following menus.

### REMEMBER:

**YOU MUST EITHER RECALIBRATE OR ENTER YOUR ORIGINAL CALIBRATION DATA.**

---

## FACILITIES AVAILABLE

---

### Introduction

The Masterweigh is a precision microprocessor based instrument for accurate integration of mass totals in belt scale and weighfeeder applications. A wide range of facilities are provided, each of which is described below.

Note that detailed information relating to the keyboard operating command procedures is to be found earlier in this manual.

### Load Cell Input and Excitation

The Masterweigh is designed to accept a loadcell millivolt signal in the range 0 to 32 millivolts with a resolution of approximately 4 microvolts.

An on-card voltage source provides excitation for the load-cell. This source can provide excitation for up to seven 350 ohm loadcells in parallel.

The excitation is not precisely controlled, but is maintained within approximately 1 percent of the set value. The Masterweigh monitors the excitation voltage and automatically compensates for any voltage change which may occur.

The excitation is adjustable over a wide range to enable optimum performance to be obtained from a wide variety of loadcells.

The Masterweigh may be configured to provide either a positive excitation voltage referenced to ground (unipolar) or a plus/minus (bipolar) voltage, by configuration of links. The positive voltage is continuously adjustable from +9 to +12 volts. The negative voltage is set at -12 volts. The Masterweigh is factory set for a unipolar excitation of 10 volts.

Following adjustment of the excitation, allow a minimum of 30 seconds for the Masterweigh to update its internal excitation reading before proceeding with calibration functions.

The approximate value of the excitation voltage sensed by the Masterweigh is displayed in Menu 8. This should match the voltage sensed at terminals 19 and 20, if link LK3 is correctly installed, and should be checked when configuring the Masterweigh. (Allow 30 seconds for update of display after adjusting the excitation).

Incorrect configuration of excitation sensing will cause erratic mass rate readings.

The millivolt input accepts either a differential millivolt signal or a half-bridge input and will operate accurately over a common mode range of minus 8 to plus 8 volts. The input is overload protected to plus or minus 35 volts on either terminal with the Masterweigh energised, and plus or minus 20 volts on either terminal when not energised. Transient overload capacity is much higher than this continuous rating, and depends on the duration of the overload.

The analog digital conversion is performed using voltage to frequency conversion techniques, thereby providing excellent rejection of signal noise over a wide frequency range.

With the exception of short periods allocated to self-calibration and reading of the auxiliary input channel, the Masterweigh is continuously monitoring the load-cell input rather than periodically sampling, as is the case for systems which use dual-slope integrating converters. This results in a more accurate measurement of the rapidly fluctuating input signal from the load-cell.

---

## FACILITIES AVAILABLE (CONT'D)

---

### Loadcell Input and Excitation (Contd.)

Careful design of the input circuitry ensures excellent rejection of common-mode signals both AC and DC.

Note: The excitation voltage regulators are overload and short-circuit protected, however, short circuiting of the excitation output will interfere with normal operation of analog input circuitry and the RS232 interface.

**Caution: Application of an external voltage source to the excitation terminals may cause serious damage to the Masterweigh.**

No calibration or adjustment of the Masterweigh analog inputs is required, other than the calibration of the current loop input in menu 15. Gain and zero are automatically adjusted by the reference. This automatic calibration is repeated once every 30 seconds, whenever the Masterweigh is energised.

After energising the Masterweigh, always allow a minimum of thirty (30) seconds for this automatic calibration to be performed before initiating a span or zero calibration sequence. (Note: If Masterweigh has not been energised for some time, allow 3 minutes before initiating the above).

An auxiliary analog input channel has been provided for sensing of a 0 to 20mA signal for cascade control or blending functions. The input includes a one ohm burden on the current loop, and thus drops 20 millivolts at 20mA. It is not an isolated input, and thus the current loop must include an appropriate ground reference.

The input will operate over a common mode range of -8 to +8 volts. The loop supply would normally be earthed at the transmitter end. It must be earthed at one point only. The input circuitry provides excellent common mode rejection of AC noise, however, the peak AC noise voltage must not exceed 8 volts.

If the Masterweigh is not earth referenced, then one side of the auxiliary input must be connected to the adjacent ground (shield) terminal to provide a voltage reference point. (Refer to Section "Earthing" for a discussion of the earth reference link).

The maximum allowable input overload current is 500mA. The maximum allowable continuous voltage on either input terminal is plus or minus 35V DC or AC measured with respect to the Masterweigh ground (plus or minus 20 volts with the Masterweigh de-energised).

Note: The auxiliary input may be converted to a millivolt input by removing the current shunt resistor R22. The input will then have the same characteristics as the loadcell input.

### Tacho Input and Supply a) Electrical Characteristics

The tacho input is designed to accept a voltage input of 2.5 to 50 volts peak and so will accept either a TTL or sinusoidal voltage input. The input threshold voltage is +1.2 volts at the positive input with respect to the negative input. The negative input is directly connected to the Masterweigh grounds. Avoid earthing this input in the field as it will create ground loops.

The tacho input will not accept frequencies in excess of 900 Hz (approx.).

---

## FACILITIES AVAILABLE (CONT'D)

---

### Tacho Input and Supply (Contd.)

A regulated +5 volt supply is provided for energising a digital pulse generator. This supply is rated at 200mA maximum and is overload and short-circuit proof with fold-back current limiting.

It may be necessary to briefly remove all load after removing a short circuit in order to reset the protection circuit. Short-circuiting of the tacho +5 volt supply will not affect the Masterweigh CPU operation.

**CAUTION: Application of an external voltage source to the tacho supply terminals may cause damage to the Masterweigh.**

### b) Frequency Selection

The tacho generator should be selected and fitted to provide a frequency input to the Masterweigh within the range 5 to 1000 Hz, to ensure compatibility & accurate measurement.

Note that the tacho frequency has no effect on the rate at which the load cell signal is sampled.

### Pulse Output

The Masterweigh provides a pulse output for external accumulation of the mass total. One 100-millisecond pulse is output each time the least significant mass total digit displayed is incremented by 1 count. A minimum of 100 milliseconds is guaranteed between pulses, thereby providing a maximum pulse rate of 5 pulses per second. (100 milliseconds on, plus 100 milliseconds off).

**NOTE:** Pulse width can be changed in Menu 1 to 100m/s, 200m/s or 300m/s.

The output is a current-limited transistor driver which can drive loads of up to 500mA. It is short-circuit protected. The driver operates with any supply voltage up to 45 volts DC and can use either an internal or external supply as required.

The internal supply is an unregulated DC supply of normal 28 volts. It is brought into circuit by appropriate configuration of links on the Masterweigh board. This internal supply is rated to a maximum continuous current of 400mA and may vary over the range 25 - 35 V DC, depending on mains voltage fluctuations and load.

Note that this supply can also be used for the analog output current loops. To use an external supply, reconfigure the links and connect a DC supply to the "28V DC" terminal adjacent to the pulse output. The pulse output is optically isolated and floats independent of the Masterweigh ground. The 28V DC supply provided on the Masterweigh is isolated from the digital ground to allow configuration of a fully-isolated pulse or analog output. The 28V DC supply is rated at 400mA maximum and is overload and short-circuit protected.

### Analog Outputs

The Masterweigh provides two independent, fully isolated analog output channels. The outputs operate over a 4-20mA range and provide a resolution of better than 0.5%. They operate as a loop-powered configuration and therefore derive their operating power from the 4mA residual loop current. A minimum of 20 volts is required to operate with zero ohms load, rising by 1 volt for every 50 ohms of load, ie. 30 volt supply required for 500 ohm load.

## FACILITIES AVAILABLE (CONT'D)

---

### Analog Outputs (Contd.)

The output can operate with supply voltage of up to 50 volts and provides excellent rejection of power supply ripple and noise. The loop power supply thus need not be heavily filtered or regulated.

An unregulated DC supply is provided on the Masterweigh board, which can be used for energisation of the analog loops and the external pulse counting device.

This supply provides a nominal 28V DC and is isolated from the Masterweigh ground. Links are provided on the board to enable this supply to energise either or both the analog outputs.

Note that if a common supply is used for the two outputs, they are no longer independently floating and cannot be referenced to separate earthing points.

To use an external loop supply, configure the links on the board appropriately and connect the external supply in series with loop in question.

Span calibration of the outputs is readily performed by shorting the calibration link associated with each channel. This forces the digital input to full scale and allows easy adjustment of the full-scale current using the potentiometer provided.

There is no provision for zero adjustment on the analog outputs.

### Earthing

The Masterweigh power supply provides transformer isolation from the mains input and thus can be operated in a floating mode if required.

For safety reasons it is recommended to reference the unit to earth. This is achieved by installing the soldered earth link "ETH LK" located adjacent to the main power connector J1. This link is normally installed at the factory and may be cut if it is desired to "float" the unit.

### Display Backlighting

The liquid-crystal display used in the Masterweigh provides LED backlighting for improved readability under adverse light conditions.

Should backlighting not be required then it can be disabled by removing link 15. Note that inserting link 15 while the unit is running may cause a reset to occur. If EL backlighting is being used (there is a yellow or black transformer in position U57, not a resistor), it is recommended that link 15 not be installed unless the inverter output is connected to a display module (Connector J2), as damage to the inverter may otherwise result.

---

## USER CONFIGURATION

---

Refer to Dwg. T144-12 "Link Configuration Details".

### LK1 Excitation Selection

This link allows the user to select either a unipolar or bipolar excitation voltage.

Refer also to Section "Load-cell Input and Excitation".

Unipolar is used for excitation voltages in the range 9 to 13 volts. Selecting bipolar allows a plus/minus excitation with a total voltage within the range 21 to 25 volts.

### LK2 On-Board Half Bridge

This link allows use of input devices which have a half bridge configuration.

When linked for half bridge input, the negative side of the "loadcell" input is disconnected from the terminal block (J6), and instead connected to an on-board half bridge circuit. This half bridge is energised from the excitation as supplied to the external device.

The zero point is adjustable via RV2. (Refer to Section "Potentiometer Adjustments, RV2").

### LK3 Excitation Feedback Sensing

The Masterweigh monitors the excitation voltage level, to enable correction for small voltage fluctuations. If the gain of the unit is changed to allow a different input voltage range, then this link must be changed to provide the appropriate excitation sensing voltage.

Link (LK7) determines the gain of the input, and thus the appropriate configuration of LK3.

Refer "Link Configuration Detail" drawing for options.

### LK4, LK5 Precision Reference Selection

The Masterweigh continuously calibrates its input circuitry against its precision reference source.

When the gain of the unit is changed via link 7, these 3 links must be re-configured as shown on the "Link Configuration Detail" drawing.

Note: The auto calibration of the unit via the precision reference affects all inputs and displayed quantities, including the millivolts displayed in menu 8.

To confirm that this auto calibration is working correctly, check the zero and scaling of the millivolt display against a meter, accurate within 0.1 %.

### LK7 Analog Gain Selection

This link selects between the two alternative input voltage ranges.

The input voltage ranges available are:-0 - 35 mV and 0 - 3.5 V

Note that the Masterweigh will read inputs of more than double these nominal full scale values, however a linearity error of the order of 0.25% may be introduced at these levels.

Note: Links LK3, LK4, LK5 and LK6 must be re-configured when LK7 is changed.

---

## USER CONFIGURATION (CONT'D)

---

### **LK8,LK9 External Pulse Counter Power Supply**

These links allow the Masterweigh to be configured to use either an internal or external power supply for the pulse counter output. Please refer to Pulse Output Section for details. When linked for external supply, an external power supply must be connected between terminals 5 ('EXT 28V DC') and 7 ('Gnd').

### **LK10, LK11 Full-scale Calibration: Analog Outputs**

When installed, these two links force their respective analog output channels to full scale to simplify the calibration procedure.

With the exception of the microprocessor output latches and opto isolators, all normal circuitry of the respective analog output channel is used, thus providing a useful check of the D/A converter, output amplifier, and pass transistor.

Refer Section "Potentiometer Adjustments, RV4, RV5" for calibration details.

Ensure that these links are removed after calibration or testing, to allow normal output current control.

### **LK12, LK14 Analog Output Supply Selection**

These links allow the Masterweigh to be configured to use either an internal or external loop power supply for each of the two analog output channels.

Note that these outputs are "loop powered" and thus do not have separate power supply terminals.

If external loop supply is selected, an appropriate power supply must be connected in series with that current loop.

### **LK13 Memory Map Select**

This link is provided to enable possible elimination of the monitor EPROM at a later date. The link is factory installed to select the 27256 EPROM with a base address of 0000.

### **LK15 Power Supply for Electro Luminescent Backlighting**

If EL backlighting is being used ( there is a yellow or black transformer in position U57, not a resistor ), installing this link connects power to the DC to AC inverter which supplies approximately 100V AC to the backlighting panel in the display module. If the board is set up for LED backlighting ( there is a resistor in position U57 ), this link connects power to the LED backlight.

Note: Connecting or disconnecting the backlighting while the Masterweigh is running may cause the system to reset due to current inrush into the inverter circuit. It is recommended that the inverter not be energised without a display module connected. (Display module connects at J2).

### **LK16, LK17, LK18**

LK16 is not currently allocated.

Links LK17 and LK18 form part of the standard RS232 interface. They allow the user to select the state of the two data control inputs to the Masterweigh.

DTR - Data Terminal Ready and  
RTS - Ready To Send

Install links LK17 and LK18 in all cases except where it is specifically required that one or both of these signals originate from the external serial device. RTS can be used by an external device to suspend data transmission.

---

## POTENTIOMETER ADJUSTMENTS

---

### RV1 Excitation Level Adjustment

This potentiometer allows adjustment of the excitation output voltage, as discussed in Section "Facilities Available, Load-cell Input and Excitation".

The excitation voltage may be monitored at terminals 19 and 20 on screw terminal block J6.

### RV2 Half Bridge Zero Adjustment (Not used by Masterweigh)

This adjustment is used only when the on-board half bridge is enabled (LK2).

The potentiometer should be adjusted so that there is a small positive voltage input, as displayed on menu 8, when the external half bridge device is at its minimum output state.

### RV3 Low Voltage Threshold Adjustment

#### a) Function

The Masterweigh incorporates a low voltage detection circuit on the +5 volt logic supply to ensure that spurious CPU operations will not occur during start-up, shut down or "brown-out".

The circuit clamps a reset on the unit whenever the supply is not within specification. The circuit includes 0.15 volts of hysteresis and operates as follows:-

- . Below 4.70V - Continuous reset to CPU
- . Above 4.85V - Normal run mode
- . Reset is released at 4.85V on rising supply
- . Reset activates at 4.70V on falling supply

This potentiometer is normally set and sealed at the factory.

#### b) Initial Set Up

Connect an adjustable DC supply to pins 5 and 12 of J1. (Mains supply board disconnected).

Connect a meter to the +5V rail of the Masterweigh and a logic probe to the system reset pin. (Pin 6 of U43).

Slowly increase the input voltage until the reset condition clears. Note the voltage at which this occurs.

Adjust RV3 until the reset clears at 4.85V with a rising input. Verify that the reset reactivates at approximately 4.7V with a falling supply.

### RV4, RV5 Analog Output Span Adjustment

Potentiometers RV4 and RV5 are used to adjust the full-scale output current of the analog output channels. The output circuit is designed to have a zero error sufficiently low such that no adjustment is necessary.

To adjust an output channel, first ensure that a suitable power supply is connected in the loop. Connect an accurate current meter in series. Using the calibration links LK10 and LK11, force the output to full scale. Use the potentiometer to set the current to the desired level - usually 20.0mA.

Note that when using a one and a half digit meter of limited resolution, it may be preferable to set the current at 19.98mA to allow a lower meter range to be used.

### RV6 Display Viewing Angle Adjustment

Adjust this potentiometer for optimum display viewing conditions. Note that some darkening of the display may occur with large increases in ambient temperature. Normal contrast will return as the temperature returns to normal.



---

## RS232 INTERFACE

---

### Description

The Masterweigh unit provides a general purpose RS232 interface port. This port enables connection to a VDU, printer or another computer, for remote information display, or print out of the system configuration parameters.

The interface is normally configured for operation at 19200 Baud, with eight data bits and one stop bits. There is no received parity check, and no transmitted parity bit.

The maximum recommended transmission distance is 100 metres, using a shielded cable, however, this depends on the environment in which the cable is being run.

### Print Function

The primary use of the RS232 port to a Masterweigh user is to enable print out of all system set-up parameters. Such a print out may be done to a display terminal, or a hard copy unit.

If a "receive only" device (no keyboard) is being used, then the parameter print out may be initiated from the Masterweigh keyboard via Menu 12. All system parameters are listed, with English language descriptions for ease of interpretation. Note that this feature is not available with all versions of software.

### Commands Available

Note: HHHH is a hexadecimal number  
[ ] indicates an optional parameter.

This list of commands is available on software version AUSR\_F02. Earlier versions of software may have slightly different commands available.

#### Basic Commands :

**?** - Displays the list of available commands.

**Time** - displays the time since the Masterweigh was last restarted or reset, in the format HH:MM:SS.

**Tacho** - displays the current tacho frequency in hertz.

**VF** - displays the instantaneous load cell input in terms of counts from the V to F converter, where 8000 counts = nominal full scale.

**Header** - displays the EPROM header information and software version number.

**Configure** - resets all parameters to default if the "C" key on the Masterweigh keypad is pressed after initiating this command. Use this command to initialise a new board, or to reinstate the non-volatile memory, if its contents have become corrupted.

**Restart** - software restart of the Masterweigh

**Outoff** - freezes the current loop outputs at their current value. To restart, use the restart command. Web-Tech technicians should only use this command.

Note : Add the suffix -R after a command to execute it repeatedly, or -RL to execute repeatedly and feed a new line. These options are only available on the commands Time, Tacho, and VF.

---

## RS232 INTERFACE (CONTD.)

---

### Automatic logging commands

The Masterweigh has been equipped with several commands that provide repetitive listings of certain parameters, to allow logging of these parameters. The logs will continue to print the data until any byte is sent to Masterweigh from the communications port or the Masterweigh is reset.

Logging commands available are :

**TCLOG** - starts a log of the tachometer input frequency in hertz, writing a new value on a new line approximately 5 times a second.

**LCLOG** - starts a log of the load cell input signal in milli-volts, writing a new value on a new line approximately 5 times a second.

**MRLOG** - starts a log of the following parameters : Mass Rate ( in mass rate units ), setpoint ( in mass rate units ), PID output ( in % ), tachometer frequency ( in hertz ) , load cell input ( in mV ). The list of values are all sent on one line per sample with space delimiting, and each sample is on a new line ( ie CR and LF is sent after each sample ). This log produces one sample ( one copy of the value of each parameter ) per second.

### Modbus interrogation commands

The Masterweigh can be interrogated and controlled via a sub-set of the modbus commands, which are Query and Modify. If you wish to use these commands, please contact Web-Tech for the protocol format and the address listing.

Other commands available on earlier software versions are :

**DUMP HHHH [HHHH]**

Hexadecimal memory dump over specified range.

**IDUMP HHHH**

Interactive display of memory contents in a range of formats. Type ? for list of options when IDUMP.

**FREE** Displays units of free CPU time.

**PARAMETERS** Displays all current system parameters.

**EXIT** Exit to the debug monitor. (May require change of Monitor EPROM).

## MEMORY COMPONENTS

---

### 1. EPROMS

The Masterweigh uses 1 or 2 EPROMS, one for program storage ( U2 : 27256, essential ), and one for storage of the monitor ( U6 : 2764, optional ), which normally will never be changed.

The EPROM sizes are as follows:-

Monitor: 2764, 8 kB available, 2 kB used  
(Note: Only 2 kilobytes are addressable in this EPROM location on the Masterweigh board).

Program: 27256, 32 kB available, 24 kB used (version 9)

(Note: EPROMS must be 250ns or faster).

The windows on the EPROMS should be covered when not being erased, to prevent accidental erasure.

The program EPROM includes a check sum which is continuously verified during normal operation. Errors are flagged on the main display.

**CAUTION: Always ensure EPROMS are inserted with correct orientation. Reverse insertion will destroy the EPROM**

### 2. STATIC RAM

The Masterweigh uses 2 kB of low power static RAM.

### 3. NOV-RAM

NOV-RAM is the non-volatile memory in which all configuration data is stored. 256 bytes are provided.

This technology does not use batteries and will store data indefinitely without power.

Checksums are maintained on all data in NOV-RAM to detect data corruption or hardware failure.

Refer to the following Section "Hardware Self Checks".

## HARDWARE SELF CHECKS

---

### Introduction

A number of internal checks are performed by the Masterweigh software to ensure system integrity. Should any fault be detected, the display will commence flashing and a fault message will be displayed if the enter key is pressed when the display is in the MRMT mode.

### EPROM Checksum

The program data in EPROM is checksummed at startup and repeatedly whilst the system is running.

The checksum is stored in the 3rd and 4th locations of the EPROM and is the complement of the two LS bytes of the total of all bytes in the EPROM.

### RAM Check

The RAM is checked at start up using a simple read/write test, bottom up then top down. Any error detected will be flagged by a flashing display.

Note that since all RAM is used by the Masterweigh this test can be performed only at start up when the RAM is not in use.

### NOV-RAM Checksum Error

This indicates that data has been altered in the NOV-RAM, or in the RAM image of the NOV-RAM, without the checksum having been recomputed. This would generally indicate a software problem or operator corruption of data. This message will also be displayed if the data stored in the NOV-RAM has been corrupted (or not previously configured).

To correct a NOV-RAM checksum Error in the field, try the following procedure:

RAM Image corrupted - turn off the power momentarily to recall the correct data from NOV-RAM.

**IF THE ABOVE FAILS, REFER TO PAGE MW19 - "RESETTING MASTERWEIGH".**

---

## HARDWARE SETUP AND TROUBLESHOOTING

---

### Initial Set up

Items which will need initial calibration and possibly, periodic recalibration are as follows:-

- . Power supply under voltage level setting
- . Analog output span adjustment
- . Precision reference voltage calibration

### Power Supply Voltage Level Sensing

An undervoltage detection circuit is incorporated in the Masterweigh to ensure that spurious CPU execution does not occur during start up, shut down or 'brown out'.

Refer to Section "Potentiometer Adjustments, RV3" for further information.

### Analog Output Span Adjustment

Each of the two analog output channels include a potentiometer for adjustment of the full scale span.

Refer Section "Potentiometer Adjustment, RV4, RV5" for further information.

Note that there is no provision for adjustment of the zero on these analog outputs. Should either zero out by greater than 0.4 mA at the 4.0 mA level then check for "out-of-spec" components.

### Precision Reference Voltage Calibration

The Masterweigh employs state-of-the-art auto-calibration techniques to establish and maintain highly accurate analog input circuitry. An extremely stable voltage source provides zero and span reference inputs.

Masterweigh uses these to establish the zero offset and gain of the input circuit, and thus compensates for drift due to temperature and ageing of components. It also means that the initial gain and zero offset of the analog to digital conversion and pre-amplifier circuitry is not critical, and thus component tolerances may be relaxed.

Note that the auto-calibration includes the effect of all components which affect the accuracy of the load-cell input.

The reference circuit provided, although very stable with temperature and time, is not tightly controlled as far as initial voltage is concerned. It is therefore necessary at an early stage in the set up of the unit, to measure the actual reference voltages and to enter them into the system for storage in NOV-RAM. The values should then be checked whenever maintenance of the Masterweigh is undertaken.

Ensure that the meters used for checking the voltages are accurate to better than 0.1 % of reading at a measured voltage of 25 millivolts.

### The voltage calibration proceeds as follows:-

- Obtain a very accurate, high resolution digital voltmeter suitable for measurements at 5 and 25 millivolts with a minimum accuracy and resolution of +/- 5 microvolts for both measurements.

- Using pointed probes, connect the meter negative to the shunt on LK6 and the positive negative to the shunt on LK5, this is the "zero calibration" value and should be approximately 5 millivolts.

- Keeping the negative on LK6, move the positive to the shunt on LK4. This is the "span

---

## HARDWARE SETUP AND TROUBLESHOOTING (CONT'D)

---

calibration" value and should be between 25 and 35 millivolts.

Using the keypad, access menu 1 and enter the zero and span values, and save on return to the main display. Allow thirty (30) seconds for the system to recalibrate in accordance with the new values.

### Analog Circuitry Notes

The input is an 8 channel differential multiplexer chosen for its input overvoltage withstand capability, low leakage current, and matching of On resistance between channels.

The AD524 instrumentation amplifier is chosen for its excellent gain and zero stability, common mode rejection, and low input bias and offset currents.

Whilst the exact zero setting is not critical, it is important that we have a "live" zero to ensure satisfactory operation of the voltage to frequency (V/F) converter, with a zero volts sign at the load-cell input.

### **The zero is established by R71 and R72 and can be checked as follows:**

Apply a short-circuit to the load-cell input and, if no load-cell is connected to establish a ground path, make a connection between the input and the analog ground (shield) terminal to ensure that the input does not float outside the common-mode range of the input circuitry. With the Masterweigh operating normally measure the voltage at pin 9 of the AD524.

Since the multiplexer selects the load-cell input for 23/25ths of the input time, the voltage seen on a sampling digital voltmeter is typically quite stable and will be that signal due to the

load-cell input. (Ignore occasional deviant readings due to sampling of the cascade input).

The signal level due to the shorted input should be approximately 1 percent of full scale or at that point AD524, Pin 9, approximately 30mV, and not less than 20 mV. **Note** that this voltage is measured with respect to analog ground (Pin 6 of the AD524).

The V/F converter operates over the frequency range 0-200 kHz, for a voltage range after the AD524 of 0-3.2 volts (corresponding to a load-cell input of 32 millivolts).

Note that the V/F converter will accept inputs of up to 10 volts, as configured, with a corresponding frequency of approximately 600 kHz. Some loss of linearity occurs above 200 kHz however.

### Watchdog Circuit

The Masterweigh incorporates a watchdog circuit to ensure that a restart will occur should CPU execution be upset by some extraordinary event. The watchdog time-out period will be in the range 1-2 seconds. The watchdog may be disabled for hardware debugging purposes by temporarily removing C30.

### Signature Analysis

A 16 pin DIL pad arrangement is provided in line with the 8 CPU data lines to allow fault isolation on boards with CPU address, data, or control line faults. To use this facility, the 8 tracks between the pads would be cut and a socket soldered into place. The socket then provides access to the data lines.

A 16 pin DIL header can be used to restore the connection after any bus fault is rectified.

## FIELD TERMINAL STRIP

TERMINAL		
No.		
		19 Load-cell excitation, positive output
1	P.I.D O/P 2, 4-20 mA, current in	20 Load-cell excitation, negative output
2	P.I.D O/P 2, 4-20 mA, current out.	(-12V or 0*9V).
3	Rate O/P 1, 4-20 mA, current in	
4	Rate O/P1, 4-20mA, current out.	
5	External +28 V, (20-40 volt external supply for pulse output)	
6	Pulse output, (0-500 mA)	
7	Ground for external supply and pulse output	
8	Tacho pulse input, (2.5 to 50 volt, 5 to 800 Hz)	
9	Tacho generator supply, (+5V, 200 mA	max.)
10	Digital ground for tacho generator.	
11	Auxiliary input 2, 0-20 mA, current in	
12	current out	
13	Ground: Reference and/or shield for auxiliary inputs.	
14	Auxiliary input 1, 0-20 mA, current in	
15	current out	
16	Ground/shield for load-cell input	
17	Load-cell input, 0-32 mV, positive input	
18	Load-cell input, 0-32 mV, negative input	

---

## SECTION 6 - CALIBRATION

---

The weighfeeder has been programmed and calibrated at the factory. However, due to changes that may have occurred during transit and installation, the weighfeeder calibration should be checked. The calibrations once initiated are automatic and only require the pressing of acceptance key(s).

The two basic calibration steps are the “Zero” calibration and the “Span” calibration.

### Zero Calibration

The zero calibration is established by running the weighfeeder empty of a programmed number of belt revolutions and calculating the average load cell output during this period. The weighfeeder electronics will automatically calculate the zero value when the test has been initiated and completed. Refer to the electronics manual supplied with your WT735 (Masterweigh 1/Masterweigh 5 or Optimus) for the section called “Load Zero Calibration” for the procedure. The weighfeeder must be able to be run empty during this test, and the number of belt revolutions programmed for its duration can be found on the calibration sheets at the end of this manual.

### Span Calibration

The span calibration is generally carried out on a model WT735 weighfeeder with the use of calibration “chains”. The calibration chain consists of one or more strands of roller chain attached to a restraining bracket. The size of the chain and number of strands has been calculated by us to simulate approximately 75% of the maximum capacity. The calibration chain is placed on the belt and attached to the inlet chute (or rear wall for horseshoe inlet). The weighfeeder is run and the test is carried out over the same number of belt revolutions as the zero test. The result is compared to a value (Target Weight) calculated by us at the time of factory commissioning. The procedure for carrying out the test can be found in the “Fixed Weight Calibrate” menu of the electronics manual. The “Target Weight” can be found on the calibration sheets in this manual.

### Material Test

We strongly suggest that a material test be carried out where possible. A material test involves weighing product on an accurate static scale prior to, or after it has passed over the weighfeeder. When carrying out a material test, the following should be considered:

1. The amount of material required for the test(s) must be proportional to the weighfeeder capacity. A rule of thumb quantity would be a minimum of 3 minutes of running time at maximum capacity e.g. if the capacity is 10 tph, the amount of material would be  $10\,000\text{ kg}/60 \times 3 = 500\text{ kg}$ . A smaller amount could be used, however it must be understood that the accuracy achievable may be diminished due to the resolution used.
2. It must be guaranteed that all of the material used in the test is collected, or have passed over the weighfeeder.
3. The material feed over the weighfeeder must be continuous and consistent.

When the test(s) have been carried out any correction to the calibration can be carried out in the “Empirical Calibration” menu of the electronics (refer to the electronics manual section).



Any changes to the calibration should be recorded on the calibration sheets for future reference.



**Gear Units**  
**R..7, F..7, K..7, S..7 Series, Spiroplan® W**


**Edition**

*05/2001*





**Operating Instructions**










**10503013 / EN**



## SEW-EURODRIVE





	<b>1 Important Notes.....</b>	<b>4</b>
	<b>2 Safety Notes .....</b>	<b>5</b>
	<b>3 Gear Unit Design .....</b>	<b>7</b>
	3.1 Basic design of a helical gear unit .....	7
	3.2 Basic design of a parallel shaft helical gear unit .....	8
	3.3 Basic design of a helical-bevel gear unit.....	9
	3.4 Base design of a helical-worm gear unit .....	10
	3.5 Basic design of a Spiroplan® gear unit .....	11
	<b>4 Mechanical Installation.....</b>	<b>12</b>
	4.1 Required tools / material .....	12
	4.2 Before you begin.....	12
	4.3 Preliminary work .....	12
	4.4 Installing the gear unit.....	13
	4.5 Gear units with solid shaft.....	15
	4.6 Installation of torque arms for shaft-mounted gear units.....	17
	4.7 Installation/removal of shaft-mounted gear units with key or splines .....	19
	4.8 Installation/removal of shaft-mounted gear units with shrink disc.....	23
	4.9 Installation of the AM adapter coupling.....	25
	4.10 Installation of the AQ adapter coupling .....	27
	4.11 Installation on the AD input shaft assembly .....	28
	<b>5 Startup.....</b>	<b>30</b>
	5.1 Startup of helical-worm and Spiroplan® W gear units.....	30
	5.2 Startup of helical, parallel shaft helical and helical-bevel gear units .....	30
	<b>6 Troubleshooting.....</b>	<b>31</b>
	6.1 Gear unit problems .....	31
	<b>7 Inspection and Maintenance .....</b>	<b>32</b>
	7.1 Inspection and maintenance periods .....	32
	7.2 Lubricant replacement schedule .....	32
	7.3 Inspection/maintenance of gear units .....	33
	<b>8 Mounting Positions.....</b>	<b>34</b>
	8.1 General comments on mounting positions.....	34
	8.2 Legend for mounting position pages.....	36
	8.3 Mounting positions, helical gear units .....	37
	8.4 Mounting positions, parallel shaft helical gear units.....	42
	8.5 Mounting positions, helical-bevel gear units .....	45
	8.6 Mounting positions, helical-worm gear units .....	50
	<b>9 Lubricants.....</b>	<b>56</b>
	<b>Address List .....</b>	<b>62</b>



## 1 Important Notes

### Safety and warning notes

Please note the safety and warning notes in this publication!



#### Electrical hazard

Could result in: death or severe injuries.



#### Imminent danger

Could result in: death or severe injuries.



#### Dangerous situation

Could result in: slight or minor injuries.



#### Damaging situation

Could result in: damage of drive and operating environment.



Operating hints and useful information.



Close adherence to the Operating Instructions is the prerequisite for fault-free operation and fulfillment of any rights to claim under guarantee. Please start reading the Operating Instructions prior to operating the drive!

Keep Operating Instructions in vicinity of unit since it contains important information on service procedures.



- **Adjust lubricant fill amount and position of breather valve when changing mounting position (see section "Lubricants" and "Mounting Positions").**
- **Please see notes in section "Setup" / "Setup of Gear Unit!"**

### Disposal



(please observe the most current regulations):

- Dispose of housing parts, gears, shafts and anti-friction bearing of gear units as steel scrap. The same applies to gray cast iron parts unless there is separate collection service.
- Some worm gears are made of non-ferrous metals and must be disposed of accordingly.
- Collect waste oil and dispose according to local guidelines.

Changes to edition 04/2000 are indicated by gray bars in the margin



## 2 Safety Notes

### **Preliminary remarks**

The following safety notes are principally concerned with the use of gear units.

If using **geared motors**, please also refer to the safety notes for motors in the corresponding operating instructions.

**Please also take account of the supplementary safety notes in the individual chapters of these operating instructions.**

### **General**

During and after operation, geared motors and gear units have live and moving parts and their surfaces may be hot.

**All work related to transport, putting into storage, setting up/mounting, connection, startup, maintenance and repair may only be carried out by qualified specialists in accordance with**

- the corresponding detailed operating instructions booklet(s) and wiring diagrams
- the warning and safety signs on the gear unit/geared motor
- the specific regulations and requirements for the system and
- national/regional regulations governing safety and the prevention of accidents

**Severe injuries and damage to property may result from**

- incorrect use
- incorrect installation or operation
- removal of required protective covers or the housing when this is not permitted

### **Designated use**

These geared motors/gear units are intended for industrial systems. They correspond to the applicable standards and regulations.

The technical data and the information about permitted conditions are to be found on the nameplate and in the documentation.

It is essential for all specified information to be observed!

### **Transportation / Storage**

**Inspect the delivered goods for any shipping damage as soon as you receive the delivery. Inform the shipping company immediately. It may be necessary to preclude startup.**

Tighten installed transportation lugs firmly. They are only designed for the weight of the geared motor/gear unit; do not attach any additional loads.

**The installed lifting eyebolts meet DIN 580. The loads and guidelines listed in the standard have to be observed. If there are two transportation or lifting eyebolts installed on the geared motor, you have to use both of them for transportation. The direction of the tensile force is not to exceed an angle of 45° to meet the guidelines set forth in DIN 580.**

Use suitable, sufficiently rated handling equipment if necessary. Remove any transport fixtures prior to startup.

**Setup /  
Installation**

See notes in sections "Setup" and "Installation/Removal!"

**Startup /  
Operation**

Check whether the direction of rotation is correct in **decoupled** status (also listen out for unusual grinding noises as the shaft rotates).

Secure the shaft keys for test mode without output elements. Do not render monitoring and protection equipment inoperative even for test mode.

Switch off the geared motor if in doubt whenever changes occur in relation to standard operation (e.g. increased temperature, noise, vibration). Determine the cause; contact SEW if necessary.

**Inspection /  
Maintenance**

See notes in section "Inspection/Maintenance!"




### 3 Gear Unit Design



The following illustrations represent design principles. They are merely reference tools for the spare parts lists. Deviations according to gear unit size and design are possible!

#### 3.1 Basic design of a helical gear unit



03438AXX

Fig. 1: Basic structure of helical gear units


#### Legend

1 Pinion	19 Key	42 Deep groove ball bearing	507 Shim
2 Gear	20 Breather valve	43 Key	508 Shim
3 Pinion shaft	22 Gear unit housing	45 Deep groove ball bearing	515 Shim
4 Gear	24 Lifting eyebolt	47 Circlip	516 Shim
5 Pinion shaft	25 Cylinder ball bearing	59 Screw plug	517 Shim
6 Gear	30 Deep groove ball bearing	88 Circlip	521 Shim
7 Output shaft	31 Key	100 Cover	522 Shim
8 Key	32 Spacer tube	101 Hex head screw	523 Shim
9 Oil seal	34 Cylinder ball bearing	102 Gasket	
11 Deep groove ball bearing	37 Deep groove ball bearing	131 Cap	
12 Circlip	39 Circlip	181 Cap	
17 Spacer tube	41 Circlip	506 Shim	





### 3.2 Basic design of a parallel shaft helical gear unit



03469AXX

Fig. 2: Basic design of a parallel shaft helical gear unit


#### Legend

1 Pinion	22 Gear unit housing	91 Circlip	184 Oil seal
2 Gear	25 Deep groove ball bearing	92 Disc	506 Shim
3 Pinion shaft	30 Tapered roller bearing	93 Lock washer	507 Shim
4 Gear	31 Lockwasher	94 Hex head screw	508 Shim
5 Pinion shaft	32 Spacer tube	100 Cover	515 Shim
6 Gear	37 Tapered roller bearing	101 Hex head screw	516 Shim
7 Hollow shaft	39 Circlip	102 Gasket	517 Shim
9 Oil seal	41 Circlip	131 Cap	521 Shim
11 Deep groove ball bearing	42 Deep groove ball bearing	160 Plug	522 Shim
14 Hex head screw	43 Key	161 Cap	523 Shim
16 Output flange	45 Deep groove ball bearing	165 Plug	
17 Spacer tube	59 Screw plug	168 Protection cap	
19 Key	81 O-ring	181 Cap	
20 Breather valve	88 Circlip	183 Oil seal	





### 3.3 Basic design of a helical-bevel gear unit



03486AXX

Fig.3: Basic design of a helical-bevel gear unit

#### Legend

1 Pinion	25 Tapered roller bearing	102 Adhesive and sealant	523 Shim
2 Gear	30 Tapered roller bearing	113 Wing nut	533 Shim
3 Pinion shaft	31 Key	114 Locking plate	534 Shim
4 Gear	37 Tapered roller bearing	116 Thread retention	535 Shim
5 Pinion shaft	39 Circlip	119 Spacer tube	536 Shim
6 Gear	42 Tapered roller bearing	131 Cap	537 Shim
7 Output shaft	43 Key	132 Circlip	538 Shim
8 Key	45 Tapered roller bearing	133 Spacer	542 Shim
9 Oil seal	59 Screw plug	137 Spacer	543 Shim
11 Tapered roller bearing	83 Nilos ring	161 Cap	544 Shim
12 Circlip	84 Nilos ring	506 Shim	
17 Spacer tube	88 Circlip	507 Shim	
19 Key	89 Cap	508 Shim	
20 Breather valve	100 Gear unit cover	521 Shim	
22 Gear unit housing	101 Hex head screw	522 Shim	



### 3.4 Base design of a helical-worm gear unit




Fig. 4: Basic design of a helical-worm gear unit

03487AXX

#### Legend

1	Pinion	19	Key	61	Circlip	507	Shim
2	Gear	20	Breather valve	88	Circlip	518	Shim
5	Worm	22	Gear unit housing	89	Cap	519	Shim
6	Worm gear	25	Tapered roller bearing	100	Gear unit housing	520	Shim
7	Output shaft	30	Tapered roller bearing	101	Hex head screw	521	Shim
9	Oil seal	37	Tapered roller bearing	131	Cap	522	Shim
11	Tapered roller bearing	39	Circlip	137	Spacer	523	Shim
12	Circlip	59	Screw plug	506	Shim		



### 3.5 Basic design of a SPIROPLAN® gear unit





Fig. 5: Basic design of a SPIROPLAN® gear unit

03488AXX

#### Legend

1 Pinion	19 Key	88 Circlip	251 Circlip
6 Gear	22 Gear unit housing	89 Cap	518 Shim
7 Output shaft	25 Deep groove ball bearing	100 Gear unit cover	519 Shim
8 Key	34 Deep groove ball bearing	101 Hex head screw	520 Shim
9 Oil seals	35 Circlip	102 Gasket	521 Shim
11 Deep groove ball bearing	65 Oil seal	132 Circlip	522 Shim
12 Circlip	71 Spacer	183 Oil ring	523 Shim
17 Spacer tube	72 Spacer	250 Circlip	



## 4 Mechanical Installation

### 4.1 Required tools / material

- Set of spanners
- Torque wrench (for shrink discs, AQ motor adapter, input shaft assembly with centering shoulder)
- Mounting device
- Shims and distance rings, if necessary
- Fastening devices for input and output elements
- Lubricant (e.g. NOCO<sup>®</sup> fluid)
- Agent for securing screws, e.g. Loctite 243 (for input shaft assembly with centering shoulder)

#### Mounting tolerances

Shaft end	Flanges
Diameter tolerance according to DIN 748 <ul style="list-style-type: none"> <li>• ISO k6 for solid shafts with <math>\varnothing \leq 50</math> mm</li> <li>• ISO m6 for solid shafts with <math>\varnothing &gt; 50</math> mm</li> <li>• ISO H7 for hollow shafts</li> <li>• Center hole according to DIN 332, shape DR..</li> </ul>	Centering shoulder tolerance according to DIN 42948 <ul style="list-style-type: none"> <li>• ISO j6 with <math>b1 \leq 230</math> mm</li> <li>• ISO h6 with <math>b1 &gt; 230</math> mm</li> </ul>

### 4.2 Before you begin

#### The drive may only be installed if

- the entries on the name plate of the drive match the mains power supply,
- the drive is undamaged (no damage caused by transport or storage) and
- it is certain that the following requirements have been fulfilled:
  - **with standard gear units:**  
ambient temperature according to lubricant table in section lubricants (see standard), no oil, acid, gas, vapors, radiation, etc.
  - **with special versions:**  
drive configured in accordance with the ambient conditions
  - **with helical worm/Spiroplan<sup>®</sup> W gear units:**  
no large external mass moments of inertia which could exert a retrodriving load on the gear unit  
[where  $h'$  (retrodriving) =  $2 - 1/\eta < 0.5$  self-locking]

### 4.3 Preliminary work

The output shafts and flange surfaces must be thoroughly cleaned of anti-corrosion agents, contamination or such like (use a commercially available solvent). Do not let the solvent come into contact with the sealing lips of the oil seals – material damage!

#### Long-term storage of gear units

Gear units of the “extended storage” type have

- a mineral oil fill (CLP) or synthetic oil fill (CLPHC) suitable for the mounting position so the unit is ready to run. However, you should still check the oil level prior to startup (see section "Inspection/Maintenance" / "Inspection/Maintenance work").
- a higher oil level with synthetic oil CLP PG). Correct the oil level prior to startup (see section "Inspection/Maintenance" / "Inspection/Maintenance work").



#### 4.4 Installing the gear unit

The gear unit or geared motor must be mounted/installed in the specified mounting position on a level<sup>1</sup>, vibration-absorbing and torsionally rigid support structure (Spiroplan® gear units are not dependent on mounting position). Do not tighten housing legs and mounting flanges against each other and pay attention to the approved overhung and axial loads

Use only bolts of 8.8 quality for installation of the geared motors

Use bolts of **10.9 quality** for fastening of flanges to transmit the rated torques listed in the catalog for the following helical geared motors in flange design (RF..) and in foot/flange version (R..F):

- RF37, R37F with flange-Ø 120 mm
- RF47, R47F with flange-Ø 140 mm
- RF57, R57F with flange-Ø 160 mm



**Oil check screws, drain screws and breather valves have to be freely accessible!**

At this point of assembly, please check that the oil filling is as prescribed for the mounting position (see "Lubricants" / "Lubricant fill levels" or data on nameplate). **In case of mounting position change, adjust lubricant filling quantities accordingly.**

Please consult our service department, if the mounting position for K gear units is changed to M5 or M6 or within these mounting positions.

Please consult our service department, if the mounting position of S units in sizes S47 ... S97 is to be changed to mounting position M2.

Use plastic inserts (2 – 3 mm thick) if there is a risk of electrochemical corrosion between the gear unit and the driven machine (connection between different metals such as cast iron and high-grade steel)! Also fit the bolts with plastic washers! Ground the housing additionally – use the grounding bolts on the motor.

Gear units are supplied in corrosion-resistant versions for use in damp areas or in the open air. Any damage to the paintwork (e.g. on the breather valve) must be repaired.

*Installation in damp areas or in the open*

1. Maximum permitted flatness error for flange mounting (approximate values with reference to DIN ISO 1101): with → flange 120...600 mm max. error 0.2...0.5 mm

**Gear unit venting**

No ventilation is required for R17, R27 and F27 gear units in mounting positions M1, M3, M5 and M6 as well as Spiroplan® W gear units.

All other gear units are delivered by SEW ready for the mounting position with the breather valve and transport fixture fitted.

**Exceptions:**


Gear units for long-term storage, in pivoting or inclined mounting positions are supplied with a screw plug installed in the provided vent hole. Prior to startup, the customer must replace screw plug at the highest location by the supplied breather valve.

- **With geared motors** for long-term storage, pivoting or inclined mounting positions, the supplied breather valve is located in the **motor terminal box**.
- **With gear head units** that have to be vented on the input side, the breather valve is supplied in a plastic bag.
- **No breather valve** will be supplied **for gear units in enclosed design**.


**Activating the breather valve**

**Usually the breather valve is activated in the plant. Should this not be the case, the transport fixture must be removed from the breather valve prior to the startup of the gear unit!**


1. Breather valve with transport fixture
2. Remove transport fixture
3. Activate breather valve



02053BXX



02054BXX



02055BXX

**Painting the gear unit**


Cover breather valve and oil seals with protective tape prior to painting or partly repainting the drive. Remove adhesive strips when the paint job is finished.




#### 4.5 Gear units with solid shaft

##### Installation of input and output elements

The following illustration is an example of a mounting device for mounting couplings or hubs onto gear unit or motor shaft ends. It may be possible to dispense with the thrust bearing on the mounting device.



The following illustration displays the correct mounting arrangement **B** of a gear wheel or sprocket to prevent excessively high overhung loads.



03369BXX



- Only use a mounting device (see Fig. 1) for installing input and output elements. Use the center bore and the thread on the shaft end for positioning purposes.
- **Never drive belt pulleys, couplings, pinions, etc. onto the shaft end by hitting them with a hammer (damage to bearings, housing and the shaft!).**
- **In the case of belt pulleys, make sure the belt is tensioned correctly (in accordance with the manufacturer's instructions).**
- Power transmission elements should be balanced after fitting and must not give rise to any impermissible radial or axial forces (see Fig. 2 / permitted values see the "Geared Motors" catalog).



##### Note:


Assembly is easier if you first apply lubricant to the output element or heat it up briefly (to 80-100 °C).



### Installation of couplings

Harmonize the following factors according to the manufacturer's recommendation when installing couplings:

- a) maximum and minimum distance
- b) axial misalignment
- c) angular misalignment




03356AXX

Fig. 6: Distance and misalignment with coupling installation



**Drive and output elements such as belt pulleys, couplings, etc. must be equipped with a touchguard!**






#### 4.6 Installation of torque arms for shaft-mounted gear units

Do not strain torque arms during installation!

**Parallel shaft  
helical gear units**




01029BXX

Fig. 7: Torque arm for parallel shaft gear units

**Helical-bevel gear  
units**

- Bushing with bearings on both ends → (1)
- Install connection end B as a mirror image of A



01030CXX

Fig. 8: Torque arm for helical-bevel gear units



### Helical-worm gear units

- Bushing with bearings on both ends → (1)




Fig. 9: Torque arm for helical-worm gear units

01031CXX

### SPIROPLAN® W gear units

- Bushing with bearings on both ends → (1)




Fig. 10: Torque arm for SPIROPLAN® W gear units

02050CXX




#### 4.7 Installation/removal of shaft-mounted gear units with key or splines



Note the construction notes in the Geared Motors catalog when designing the customer shaft!


##### Installation notes

1. Apply NOCO<sup>®</sup> fluid



02042BXX


2. Distribute NOCO<sup>®</sup> fluid evenly





02043AXX

3. Install shaft and secure axially  
(installation will be made easier by using a mounting device)


##### 3A: Installation with standard components



- 1 short retaining screw  
(standard components)
- 2 lock washer
- 3 washer
- 4 circlip
- 6 customer shaft

**3B: Installation with SEW installation/removal kit (→ page 22)**– Customer shaft **with** contact shoulder**3C: Installation with SEW installation/removal kit (→ page 22)**– Customer shaft **without** contact shoulder

4. Tighten retaining screw with corresponding torque (see table).



Screw	Torque [Nm]
M5	5
M6	8
M10/12	20
M16	40
M30	80
M24	200


**Note:**

We recommend you also loosen the customer shaft between the two contact surfaces to prevent contact corrosion!

**Removal notes**

The description applies only to gear units that were installed with the SWE mounting/removal kit (→ page 22) (see previous description, points 3B or 3C)


1. Loosen the retaining screw 1.
2. Remove parts 2 to 4 and the spacer tube 5, if installed.



- 1 retaining screw
- 2 lock washer
- 3 washer
- 4 circlip
- 5 spacer tube
- 6 customer shaft

03366AXX

3. Install the removal washer 8 and the locknut 7 from the SEW installation/removal kit between customer shaft 6 and circlip 4.
4. Reinstall the circlip 4.
5. Reinstall the retaining screw 1. You can now remove the gear unit from the shaft by tightening the screw.



- 1 retaining screw
- 4 circlip
- 6 customer shaft
- 7 locknut
- 8 removal washer

03367AXX


**SEW installation/  
removal kit**

The SEW installation/removal kit is available with the indicated part number.




Fig. 11: SEW installation/removal kit

03394CXX

- 1 retaining screw
- 7 locknut for removal
- 8 removal washer

Type	D <sup>H7</sup> [mm]	M <sup>1)</sup>	C4 [mm]	C5 [mm]	C6 [mm]	U <sup>-0.5</sup> [mm]	T <sup>-0.5</sup> [mm]	D3 <sup>-0.5</sup> [mm]	L4 [mm]	Part number installation/ removal kit
WA..10	16	M5	5	5	12	4.5	18	15.7	50	643 712 5
WA..20	18	M6	5	6	13.5	5.5	20.5	17.7	25	643 682 X
WA..20, WA..30, SA..37	20	M6	5	6	15.5	5.5	22.5	19.7	25	643 683 8
FA..27, SA..47	25	M10	5	10	20	7.5	28	24.7	35	643 684 6
FA..37, KA..37, SA..47, SA..57	30	M10	5	10	25	7.5	33	29.7	35	643 685 4
FA..47, KA..47, SA..57	35	M12	5	12	29	9.5	38	34.7	45	643 686 2
FA..57, KA..57, FA..67, KA..67, SA..67	40	M16	5	12	34	11.5	41.9	39.7	50	643 687 0
SA..67	45	M16	5	12	38.5	13.5	48.5	44.7	50	643 688 9
FA..77, KA..77, SA..77	50	M16	5	12	43.5	13.5	53.5	49.7	50	643 689 7
FA..87, KA..87, SA..77, SA..87	60	M20	5	16	56	17.5	64	59.7	60	643 690 0
FA..97, KA..97, SA..87, SA..97	70	M20	5	16	65.5	19.5	74.5	69.7	60	643 691 9
FA..107, KA..107, SA..97	90	M24	5	20	80	24.5	95	89.7	70	643 692 7
FA..127, KA..127	100	M24	5	20	89	27.5	106	99.7	70	643 693 5
FA..157, KA..157	120	M24	5	20	107	31	127	119.7	70	643 694 3

1) retaining screw




#### 4.8 Installation/removal of shaft-mounted gear units with shrink disc

**Installation notes**


- Do not tighten locking screws unless shaft is installed - hollow shaft could be deformed!

1. Thoroughly remove grease from hollow shaft bore and drive shaft.

2. Degreased hollow shaft/drive shaft




01815AXX




01816AXX

3. Apply NOCO® fluid in the bushing area onto the input shaft<sup>1)</sup>.

4. Install shaft, making sure that the locking collars of the shrink disc are evenly spaced<sup>2)</sup>.



01817AXX




01818AXX



- The clamping area of the shrink disc must always be kept free from grease! Therefore, never apply NOCO® fluid directly onto the bushing, since the paste can enter the clamping area of the shrink disc when installing the input shaft.**
- After installation**, grease the outer surface of the hollow shaft in the shrink disc area to protect the shaft against corrosion.



5. Tighten the locking screws by working round several times from one screw to the next (not diagonally). See table for tightening torques.



01819AXX

Gear unit type			Screw	Nm	max. <sup>1)</sup>
FH27	SH37		M5	5	60°
KH37...77	FH37...77	SH47...77	M6	12	
KH87/97	FH87/97	SH87/97	M8	30	
KH107	FH107		M10	59	
KH127/157	FH127		M12	100	

1) maximum tightening angle per cycle

#### Notes on removal of shrink disc

1. Unscrew the locking screws evenly one after the other. To avoid tilting and jamming of the locking collars, each locking screw may only be unscrewed by about one quarter turn in the initial cycle. Do not fully unscrew the locking screws!
2. Remove the shaft or pull the hub off the shaft (it is necessary to remove any rust which may have formed between the hub and the end of the shaft).
3. Pull the shrink disc off the hub..



#### Caution!

There is a risk of injuries if the shrink disc is not removed correctly!

#### Cleaning and lubricating the shrink disc

There is no need to take apart and re-grease disassembled shrink discs before they are screwed back on.

The shrink disc only needs to be cleaned and re-greased if it is contaminated.

Use one of the following solid lubricants for the tapered surfaces.

Lubricant (Mo S2)	Available as
Molykote 321 (lube coat)	spray
Molykote Spray (powder spray)	spray
Molykote G Rapid	spray or paste
Aemasol MO 19P	spray or paste
AemasolDIO-sétral 57 N (lube coat)	spray

Grease the locking screws with a multipurpose grease such as Molykote BR 2 or similar.






#### 4.9 Installation of the AM adapter coupling

**IEC adapters**

**AM63 - 225 /**

**NEMA adapters**

**AM56 - 365**



\* = NEMA adapters only  
1 = motor shaft

04469AXX


1. Clean motor shaft and flange surfaces of motor and adapter.
2. **IEC adapters:** Remove motor shaft key and replace with supplied key (484).  
**NEMA adapters:** Remove motor shaft key, slide spacer tube (491) on motor shaft and install supplied key (484).
3. Heat coupling half (479) to approx. 80 - 100°C; slide coupling half on motor shaft.  
**IEC adapters:** until rest on motor shaft shoulder.  
**NEMA adapters:** until rest on spacer tube.
4. Secure key and coupling half with setscrew (481) on motor shaft .
5. Mount motor to adapter; the gearing of the coupling half and the geared adapter shaft must enmesh.



Note: We recommend applying Noco<sup>®</sup> fluid on the motor shaft prior to installation of the coupling half to prevent contact corrosion.



**IEC adapters  
AM250/AM280**



02047CXX


1. Clean motor shaft and flange surfaces of motor and adapter.
2. Remove motor shaft key and replace with supplied key (**size AM280 only**).
3. Heat coupling half (479) (to 80 °C - 100 °C) and slide on motor shaft (A = 139 mm).
4. Fasten coupling half with setscrew and check position (distance "A").
5. Mount motor on adapter; the gearing of the coupling half and the geared adapter shaft must enmesh.



Note: We recommend applying Noco<sup>®</sup> fluid on the motor shaft prior to installation of the coupling half to prevent contact corrosion.



#### 4.10 Installation of the AQ adapter coupling



1. Clean motor shaft and flange surfaces of motor and adapter.
2. **AQH design:** Slide spacer tube (491) on motor shaft.
3. **AQH design:** Loosen screws of coupling half (479) and conical connection.
4. Heat coupling half (80° C - 100° C) and slide on motor shaft.
  - AQH design:** until rest on spacer tube (491).
  - AQA design:** until distance "A" (see table)
5. **AQH design:** Fasten screws of coupling half evenly by working round several times in sequence until all screws have been tightened to the TT tightening torque.
  - AQA design:** Secure coupling half with setscrew.
6. Check position of coupling half (distance "A" see table).

Mount motor to adapter; the jaws of both coupling halves must enmesh. The insertion force required to join the coupling halves. The insertion force required to join the coupling halves is suspended after final assembly thereby causing danger of axial load on the adjacent bearing.

#### Setting dimensions, tightening torques

Type	Coupling size	Distance "A" [mm]	Bolts DIN 912 <sup>1)</sup>	Tightening torque TT <sup>1)</sup> [Nm]
AQA /AQH 80 /1/2/3	19/24	44.5	M4	3
AQA /AQH 100 /1/2		39		
AQA /AQH 100 /3/4		53		
AQA /AQH 115 /1/2		62		
AQA /AQH 115 /3	24/28	62	M5	6
AQA /AQH 140 /1/2		62		
AQA /AQH 140 /3	28/38	74.5	M5	6
AQA /AQH 190 /1/2		76.5		
AQA /AQH 190 /3	38/45	100	M6	10

1) in versions without keyway only (AQH)




#### 4.11 Installation on the AD input shaft assembly

See section "Installation of input and output shafts" for installation of input elements.

**Version with  
motor mounting  
platform AD../P**

Installation of motor and adjustment of motor mounting platform



- 1 Motor mounting platform
- 2 Setscrew (AD6/P / AD7/P only)
- 3 Support (AD6/P / AD7/P only)
- 4 Nut
- 5 Threaded column

03519BXX

1. Adjust motor mounting platform to required mounting position by evenly tightening the adjusting nuts. For the lowest possible adjustment position of helical gear units, remove eyebolts/transport lugs if there are any; touch up any damage to protective coating.
2. Align motor on motor mounting plate (shaft extensions must be aligned) and secure it.
3. Mount drive elements onto input shaft extension and install motor shaft, align these to each other; correct motor position where necessary.
4. Install traction mechanisms (V-belts, chains, ...) and tighten by evenly adjusting the motor mounting plate. The motor mounting plate and columns must not be tightened against each other.
5. Secure threaded columns with the nuts not used for adjustment purposes.

**AD6/P and AD7/P  
only:**


Loosen nuts and stud bolts before readjustment so that the stud bolts can be moved freely in the support axially. Tighten nuts after the final position has been accomplished. Do not adjust the motor mounting platform by using the support.



**AD../ZR design  
with centering  
shoulder**

Installing components on the input shaft assembly with centering shoulder

1. The bolts must be available in the correct length to fasten the installed components.  
The length of the new bolts results from:



02725CXX

**The calculated screw length must be rounded down to the next smallest standard length.**

2. Remove retaining screw from centering shoulder.
3. Clean contact surface and centering shoulder.
4. Clean the threads of the new screws and apply an adhesive agent (e.g. Loctite 243) to the first turns on the screw.
5. Set component onto centering shoulder and fasten retaining screws with indicated tightening torque  $T_t$  (see table).

Type	Depth of screw t	Retaining thread s	Tightening torque $T_A$ [Nm]
AD2/ZR	25.5	M8	25
AD3/ZR	31.5	M10	48
AD4/ZR	36	M12	86
AD5/ZR	44	M12	86
AD6/ZR	48.5	M16	210
AD7/ZR	49	M20	410
AD8/ZR	42	M12	86

**AD../RS version  
with backstop**

Check the direction of rotation prior to installation or startup. In case of the wrong direction of rotation, please consult our technical department.

The backstop is maintenance-free and does not require any additional maintenance work.



## 5 Startup

### 5.1 Startup of helical-worm and Spiroplan® W gear units



Note: The direction of rotation for the output shaft has been changed from CW to CCW for helical-worm gear units S..7 series compared to the S..2 series. Switch two motor feeder cables to change the direction of rotation.

#### Running-in period

Spiroplan® and helical-worm gear units require a running-in period of at least 24 hours before reaching their maximum efficiency. A separate running-in period is required for each direction of rotation if the gear unit is operated in both directions of rotation. The table displays the average power reduction during the running-in period.

No. of starts	Helical-worm		Spiroplan®	
	power reduction	i range	power reduction	i range
1 start	approx. 12%	app. 50...280	approx. 15%	approx. 40...75
2 starts	approx. 6%	app. 20...75	approx. 10%	approx. 20...30
3 starts	approx. 3%	app. 20...90	approx. 8%	approx. 15
4 starts	-	-	approx. 8%	approx. 10
5 starts	approx. 3%	app. 6...25	approx. 5%	approx. 8
6 starts	approx. 2%	app. 7...25	-	-

### 5.2 Startup of helical, parallel shaft helical and helical-bevel gear units

There are no special startup notes that have to be observed for helical gear units, parallel shaft helical gear units and helical-bevel gear units, if the gear units have been mounted according to the section "Mechanical Installation."



## 6 Troubleshooting

### 6.1 Gear unit problems

Problem	Possible cause	Remedy
Unusual, regular running noise	A Meshing/grinding noise: bearing damage B Knocking noise: irregularity in the gearing	A Check oil (see Inspection and Maintenance), replace bearing B Call customer service
Unusual, irregular running noise	Foreign bodies in the oil	<ul style="list-style-type: none"> <li>Check oil (see Inspection and Maintenance)</li> <li>Stop the drive, call customer service</li> </ul>
Oil leaking <sup>1)</sup> <ul style="list-style-type: none"> <li>from the gear unit cover</li> <li>from the motor flange</li> <li>from motor oil seal</li> <li>from gear unit flange</li> <li>from the output end oil seal</li> </ul>	A Defective rubber gasket on gear unit cover B Defective gasket C Gear unit not vented	A Retighten screws on gear unit cover and observe gear unit. Oil still leaking: Call customer service B Call customer service C Vent the gear unit (see Mounting Positions)
Oil leaking from the breather valve	A Too much oil B Drive installed in incorrect mounting position C Frequent cold starts (oil foaming) and / or high oil level	A Correct oil level (see Inspection and Maintenance) B Fit the breather valve correctly (see Mounting Positions) and adjust oil level (see Lubricants)
Output shaft is not rotating although the motor is running or the input shaft is rotating	Shaft hub connection interrupted in the gear unit	Send in gear unit/geared motor for repair

1) It is normal for small amounts of oil/grease to leak out of the oil seal during the running-in period (24 hour running time) (also see DIN 3761).

**Please have the following information available if you require assistance of our customer service:**

- Nameplate data (complete)
- Type and extent of problem
- Time and circumstances of problem
- Possible cause




## 7 Inspection and Maintenance

### 7.1 Inspection and maintenance periods

Time period	What to do?
<ul style="list-style-type: none"> <li>every 3000 operating hours, at least every six months</li> </ul>	<ul style="list-style-type: none"> <li>Check oil</li> </ul>
<ul style="list-style-type: none"> <li>depending on operating conditions (see following illustration), at least every three years</li> </ul>	<ul style="list-style-type: none"> <li>Replace mineral oil</li> <li>Replace bearing grease</li> </ul>
<ul style="list-style-type: none"> <li>depending on operating conditions (see following illustration), at least every five years</li> </ul>	<ul style="list-style-type: none"> <li>Replace synthetic oil</li> <li>Replace bearing grease</li> </ul>
<ul style="list-style-type: none"> <li>R17, R27, F27 and Spiroplan® gear units are lubricated for life and do not require maintenance</li> </ul>	
<ul style="list-style-type: none"> <li>different (depending on external influences)</li> </ul>	<ul style="list-style-type: none"> <li>Touch up or replace surface/corrosion protection coat</li> </ul>

### 7.2 Lubricant replacement schedule

Change oil more often in special version and under more demanding/aggressive ambient conditions!



04640AXX

Fig. 12: Replacement schedule for standard gear units operating under normal ambient conditions.

- (1) Operating hours  
 (2) Oil bath steady-state temperature  
 • Average value depending on oil type at 70° C





### 7.3 Inspection/maintenance of gear units

Do not mix synthetic lubricants with each other nor with mineral lubricants!  
Mineral oil is the standard lubricant.

**The position of the oil level plug, oil drain plug and the breather valve is dependent on the mounting position.**

#### Checking the oil level



1. De-energize the drive and secure against unintentional switch-on!

**Wait until the gear unit has cooled down – Danger of burns!**

2. See section "Setup of gear unit" for change in mounting position!
3. For gear units with oil level plug: remove oil level plug, check fill level and correct if necessary, install oil level plug

#### Check oil



1. De-energize the drive and secure against unintentional switch-on!

**Wait until gear unit has cooled down - Danger of burns!**

2. Remove some oil from the oil drain plug
3. Check oil consistency
  - viscosity
  - if the oil is visibly contaminated, it is recommended to change it sooner than recommended by the maintenance intervals listed under the heading "Inspection and maintenance periods" on page 32
4. For gear units with an oil level plug: remove oil level plug, check oil fill level and correct if necessary, install oil level plug

#### Changing the oil



Only change the oil when the gear unit is at operating temperature.

1. De-energize the drive and secure against unintentional switch-on!

**Wait until the gear unit has cooled down – Danger of burns!**

**Note: Gear unit must still be warm, otherwise the high viscosity of excessively cold oil will make it harder to drain the oil correctly.**

2. Place a container underneath the oil drain plug
3. Remove oil level plug, breather plug/valve and oil drain plug
4. Drain oil completely
5. Install oil drain plug
6. Fill new oil of the same type through the breather hole, otherwise consult our service department
  - amount in accordance with the mounting position (see section "Lubricant fill levels") on the nameplate
  - check at the oil level plug
7. Install oil level plug
8. Install breather plug/valve

## 8 Mounting Positions

### 8.1 General comments on mounting positions

#### Mounting position designation

SEW has six mounting positions M1 ... M6 for gear units (see illustration).




Fig. 13: Mounting positions M1 ... M6

03203AXX

**Comparison  
old/new**

The following table indicates in which way the old SEW mounting position designations are integrated into the new system:

	M1	M2	M3	M4	M5	M6
<b>R, RX</b>	B3	V6	B8	V5	B6	B7
<b>R..F</b>	B35	V36	B85	V15	B65	B75
<b>RF, RXF</b>	B5	V3	B5II	V1	B5I	B5III
<b>F</b> FA..B FH..B FV..B	B6	V6	B6II	V5	B3 B8	B3I B8I
<b>FF</b>	B5	V3	B5II	V1	B5I	B5III
<b>FA</b> FHF FVF FH FAZ FV FHZ FAF FVZ	H1	H6	H2	H5	H4	H3
<b>K</b> KA..B KH..B KV..B	B3 B6I	B6 B8I	B8	B3I B6II	V5 V5I	V6 V6I
<b>K/KH</b> 166/167 186/187	B3 B5/I			B3I B5/II	V1/	V1/I
<b>KF</b>	B5I B3/B5I	B5 B65	B5III B8/B5III	B5II B6/B5II	V1 V15	V1I V6/V1I
<b>KA</b> KHF KVF KH KAZ KV KHZ KAF KVZ	H1	H4	H2	H3	H5	H6
<b>S</b>	B3 B6I B8II (S37)	B6 B8I	B8 B3II	B3I B6II	V5 V5I	V6 V6I V5II (S37)
<b>SF</b>	B5I	B5	B5III	B5II	V1	V1I
<b>SA</b> SH SAF SHF SAZ SHZ	H1	H4	H2	H3	H5	H6

04464AXX




**Example**

A KA77B helical-bevel gear unit with the old mounting position B3I or B6II, is now referred to with mounting position designation M4.

## 8.2 Legend for mounting position pages

### Used symbols

The following table contains all symbols used in the mounting position pages as well as their meaning:

Symbol	Meaning
	Breather valve
	Oil level check plug
	Oil drain plug

### Churning losses





There is a possibility of increased churning losses with some mounting positions. Please contact SEW when dealing with the following combinations:

Mounting position	Gear unit type	Gear unit size	Input speed [1/min]
M2, M4	R	97 ... 107	> 2500
		> 107	> 1500
M2, M3, M4, M5, M6	F	97 ... 107	> 2500
		> 107	> 1500
	K	77 ... 107	> 2500
		> 107	> 1500
	S	77 ... 97	> 2500

### 8.3 Mounting positions, helical gear units

R17-R167

04 040 100





- |          |  |                |
|----------|--|----------------|
| R17, R27 |  | M1, M3, M5, M6 |
| R47, R57 |  | M5             |
| R17, R27 |  |                |

\* → page 36

RF17-RF167


04 041 100

RF17, RF27  M1, M3, M5, M6RF47, RF57  M5RF17, RF27  

\* → page 36

**R17F-R87F**

**04 042 100**







R17F, R27F		M1, M3, M5, M6
R47F, R57F		M5
R17F, R27F		

\* → page 36

**Caution:** Note the notes in the "Geared Motors" catalog, section "Project Planning Gear Units/Overhung and axial loads."

RX57-RX107

04 043 100





\* → page 36



RXF57-RXF107

04 044 100




\* → page 36

### 8.4 Mounting positions, parallel shaft helical gear units

F/FA..B/FH27B-157B, FV27B-107B

42 042 100



F..27  M1, M3, M5, M6


F..27  M1 - M6


F..27  M1, M3, M5, M6

\* → page 36

FF/FAF/FHF/FAZ/FHZ27-157, FVF/FVZ27-107

42 043 100



F..27  M1, M3, M5, M6




F..27  M1 - M6

F..27  M1, M3, M5, M6

\* → page 36

FA/FH27-157, FV27-107

42 044 100


F..27  M1, M3, M5, M6F..27  M1 - M6F..27  M1, M3, M5, M6

\* → page 36


## 8.5 Mounting positions, helical-bevel gear units

K/KA..B/KH37B-157B, KV37B-107B

34 025 100





\* → page 36

**Caution:** Note the  notes in the "Geared Motors" catalog, section "Project Planning Gear Units/Overhung and axial loads."

K167-187, KH167B-187B

34 026 100




\* → page 36

**Caution:** Note the ⓘ notes in the "Geared Motors" catalog, section "Project Planning Gear Units/Overhung and axial loads."

KF/KAF/KHF/KAZ/KHZ37-157, KVF/KVZ37-107



34 027 100



\* → page 36

KA/KH37-157, KV37-107

39 025 100




\* → page 36



**KH167-187**

**39 026 100**






\* → page 36

## 8.6 Mounting positions, helical-worm gear units

S37



05 025 100



**Caution:** Note the  notes in the "Geared Motors" catalog, section "Project Planning Gear Units/Overhung and axial loads."



S47-S97

05 026 100




\* → page 36

**Caution:** Note the ⓘ notes in the "Geared Motors" catalog, section "Project Planning Gear Units/Overhung and axial loads."

**SF/SAF/SHF37****05 027 100**

SF/SAF/SHF/SAZ/SHZ47-97



05 028 100



\* → page 36



SA/SH37

28 020 100



SA/SH47-97

28 021 100



\* → page 36



## 9 Lubricants

### General





SEW supplies the drives filled with a lubricant appropriate for the specific gear unit and mounting position. The decisive factor is the indicated mounting position (M1...M6, → section "Mounting positions and important order information") when ordering the drive. The lubricant fill amounts for subsequent changes in the mounting position will have to be adjusted for the specific mounting position (→ Lubricant fill quantities).

### Lubricant table

The lubricant table for SEW drives on the following page is a list of all approved lubricants for SEW drives. Please note the following legend for the lubricant table.



### Legend for lubricant table

Abbreviations, meaning of shading and notes:

CLP	= Mineral oil
CLP PG	= Polyglykol (W gear unit, meeting USDA-H1 standard)
CLP HC	= Synthetic hydrocarbons
E	= Diester oil (water pollution class WGK 1)
HCE	= Synthetic hydrocarbons + diester oil (USDA - H1 approval)
HLP	= Hydraulic oil
	= Synthetic lubricant (= anti-friction bearing grease on synthetic base)
	= Mineral lubricant (= anti-friction bearing grease on mineral base)
1)	Helical-worm gear unit with PG oil: Please consult SEW
2)	Special lubricant for Spiroplan® gear units only
3)	Recommendation: Select SEW $f_B \geq 1.2$
4)	Note critical starting performance at low temperatures!
5)	Low-viscosity grease
6)	Ambient temperature
	Lubricant for the food industry
	Biological oil (lubricant for agricultural, forestry and water industry)

### Anti-friction bearing greases

The anti-friction bearings in SEW gear units and motors will be filled with the following greases at the factory. SEW recommends to change the grease when replacing the oil in anti-friction bearings with grease filling.

	Ambient temperature	Manufacturer	Type
Gear unit anti-friction bearing	-30°C ... +60°C	Mobil	Mobilux EP 2
	-40°C ... +80°C	Mobil	Mobiltemp SHC 100
Motor anti-friction bearing	-25°C ... +80°C	Esso	Unirex N3
	-25°C ... +60°C	Shell	Alvania R3
	+80°C ... +100°C	Klüber	Barrierta L55/2
	-45°C ... -25°C	Shell	Aero Shell Grease 16
Special greases for gear unit anti-friction bearings:			
	-30°C ... +40°C	Aral	Aral Eural Grease EP 2
	-20°C ... +40°C	Aral Klüber	Aral Aralub BAB EP 2 Klüberbio M32-82



### You need the following grease amounts:

- For fast-running bearings (motor and gear unit input side): Fill one third of the hollow spaces between the actual roller bodies with grease.
- For slow-running bearings (in gear unit and gear unit output side): Fill two thirds of the spaces between the actual roller bodies with grease.





Table of lubricants

01 805 692

	6) °C -50 0 +50 +100 Standard -10 +40	DIN (ISO) Oil	ISO, NLGI	Mobil®	Shell	KLÜBER LUBRICATION	ARAL	BP	Tribol	TEACO	Optimal	FUCHS
R...		CLP (CC)	VG 220	Mobilgear 630	Shell Omala 220	Klüberoil GEM 1-220	Aral Degol BG 220	BP Energol GR-XP 220	Tribol 1100/220	Meropa 220	Optigear BM 220	Renolin CLP 220
K... (HK...)		CLP PG	VG 220	Mobil Glygoyle 30	Shell Tivela WB	Klüberoil GH 6-220	Aral Degol GS 220	BP Energol SG-XP 220	Tribol 800/220	Synlube CLP 220	Optiflex A 220	
F...		CLP HC	VG 220	Mobilgear SHC 630	Shell Omala 220 HD	Klüberoil EG 4-220	Aral Degol PAS 220		Tribol 1510/220	Pinnacle EP 220	Optigear Synthetic A 220	Renolin Unisyn CLP 220
	4) -25		VG 150	Mobil SHC 629		Klüberoil EG 4-150				Pinnacle EP 150		
	4) -40		VG 150	Mobilgear 629	Shell Omala 100	Klüberoil GEM 1-150	Aral Degol BG 100	BP Energol GR-XP 100	Tribol 1100/100	Meropa 150	Optigear BM 100	Renolin CLP 150
		HLP (HM)	VG 68-46	Mobil D.T.E. 15M	Shell Tellus T 32	Klüberoil GEM 1-68	Aral Degol BG 46		Tribol 1100/68	Rando EP Ashless 46	Optigear 32	Renolin B 46 HVI
	4) -40	CLP HC	VG 32	Mobil SHC 624		Klüber-Summit HySyn FG-32				Cetus PAO 46		
	4) -40	HLP (HM)	VG 22	Mobil D.T.E. 11M	Shell Tellus T 15	Isotex MT 30 ROT		BP Energol HLP-HM 10		Rando HDZ 15		
		CLP (CC)	VG 680	Mobilgear 636	Shell Omala 680	Klüberoil GEM 1-680	Aral Degol BG 680	BP Energol GR-XP 680	Tribol 1100/680	Meropa 680	Optigear BM 680	Renolin CLP 680
S... (HS...)		CLP PG	VG 680 <sup>1)</sup>	Mobil Glygoyle HE 680		Klüberoil GH 6-680		BP Energol SG-XP 680	Tribol 800/680	Synlube CLP 680		
	4) -20		VG 460	Mobil SHC 634	Shell Omala 460 HD	Klüberoil EG 4-460				Pinnacle EP 460		
	4) -40		VG 150	Mobil SHC 629		Klüberoil EG 4-150				Pinnacle EP 150		
		CLP (CC)	VG 150	Mobil D.T.E. 18M	Shell Omala 100	Klüberoil GEM 1-150	Aral Degol BG 100	BP Energol GR-XP 100	Tribol 1100/100	Meropa 100	Optigear BM 100	Renolin CLP 150
		HLP (HM)	VG 100	Mobil Glygoyle 30		Klüberoil GH 6-220			Tribol 800/220	Synlube CLP 220	Optiflex A 220	
	4) -25	CLP PG	VG 220 <sup>1)</sup>			Klüber-Summit HySyn FG-32				Cetus PAO 46		
	4) -40	CLP HC	VG 32	Mobil SHC 624		Klüber-Summit HySyn FG-32						
R..., K... (HK...), F..., S... (HS...)		HCE	VG 460		Shell Cassida Fluid GL 460	Klüberoil 4UH1-460	Aral Eural Gear 460				Optileb GT 460	
		E	VG 460			Klüberoil CA2-460	Aral Degol BAB 460				Optisyn BS 460	
W... (HW...)		SEW PG	VG 460 <sup>2)</sup>			Klüber SEW HT-460-5						
	4) -30		SAE 75W90 (~VG 100)	Mobilube SHC 75 W90-LS								
	4) -40	API GL5	VG 460 <sup>3)</sup>			Klüberoil UH1 6-460						
		CLP PG	00	Glygoyle Grease 00	Shell Tivela Compound A	Klüberoil GE 46-1200				Multifak 6833 EP 00		
R32 R302		DIN 51 818 <sup>5)</sup>	000 - 0	Mobilux EP 004	Shell Alvania GL 00		Aralub MFL 00	BP Energol LS-EP 00		Multifak EP 000	Longtime PD 00	Renolin SF 7 - 041

50258AXX



### Lubricant fill quantities

The indicated fill quantities are **recommended values**. The specific values vary depending on number of stages and ratio. Pay close attention to the **oil level plug to serve as indicator for the correct amount of oil**.

The following tables list the recommended values for the lubricant fill quantities in reference to mounting positions M1...M6.

### Helical (R-) gear units

Gear units R.., R..F	Fill quantity in liters					
	M1 <sup>1)</sup>	M2 <sup>1)</sup>	M3	M4	M5	M6
R17/R17F	0.25	0.6	0.35	0.6	0.35	0.35
R27/R27F	0.25/0.4	0.7	0.4	0.7	0.4	0.4
R37/R37F	0.3/1	0.9	1	1.1	0.8	1
R47/R47F	0.7/1.5	1.6	1.5	1.7	1.5	1.5
R57/R57F	0.8/1.7	1.9	1.7	2.1	1.7	1.7
R67/R67F	1.1/2.3	2.6/3.5	2.8	3.2	1.8	2
R77/R77F	1.2 / 3	3.8 / 4.3	3.6	4.3	2.5	3.4
R87/R87F	2.3 / 6	6.7 / 8.4	7.2	7.7	6.3	6.5
R97	4.6/9.8	11.7/14	11.7	13.4	11.3	11.7
R107	6/13.7	16.3	16.9	19.2	13.2	15.9
R137	10/25	28	29.5	31.5	25	25
R147	15.4/40	46.5	48	52	39.5	41
R167	27/70	82	78	88	66	69
Gear units RF..	Fill quantity in liters					
	M1 <sup>1)</sup>	M2 <sup>1)</sup>	M3	M4	M5	M6
RF17	0.25	0.6	0.35	0.6	0.35	0.35
RF27	0.25/0.4	0.7	0.4	0.7	0.4	0.4
RF37	0.4/1	0.9	1	1.1	0.8	1
RF47	0.7/1.5	1.6	1.5	1.7	1.5	1.5
RF/RM57	0.8/1.7	1.8	1.7	2	1.7	1.7
RF/RM67	1.2/2.5	2.7/3.6	2.7	3.1	1.9	2.1
RF/RM77	1.2 / 2.6	3.8/4.1	3.3	4.1	2.4	3
RF/RM87	2.4 / 6	6.8/7.9	7.1	7.7	6.3	6.4
RF/RM97	5.1/10.2	11.9/14	11.2	14	11.2	11.8
RF/RM107	6.3/14.9	15.9	17	19.2	13.1	15.9
RF/RM137	9.5/25	27	29	32.5	25	25
RF/RM147	16.4/42	47	48	52	42	42
RF/RM167	26/70	82	78	88	65	71

1) The larger gear unit in multi-stage gear units must be filled with the larger oil quantity.

Gear units RX..	Fill quantity in liters					
	M1	M2	M3	M4	M5	M6
RX57	0.6	0.8	1.3	1.3	0.9	0.9
RX67	0.8	0.8	1.7	1.9	1.1	1.1
RX77	1.1	1.5	2.6	2.7	1.6	1.6
RX87	1.7	2.5	4.8	4.8	2.9	2.9
RX97	2.1	3.4	7.4	7	4.8	4.8
RX107	3.9	5.6	11.6	11.9	7.7	7.7
Gear units RXF..	Fill quantity in liters					
	M1	M2	M3	M4	M5	M6
RXF57	0.5	0.8	1.1	1.1	0.7	0.7
RXF67	0.7	0.8	1.5	1.7	1	1
RXF77	0.9	1.5	2.4	2.5	1.6	1.6
RXF87	1.6	2.5	4.9	4.7	2.9	2.9
RXF97	2.1	3.6	7.1	7	4.8	4.8
RXF107	3.1	5.9	11.2	10.5	7.2	7.2



Parallel shaft heli-  
cal (F-) gear units

F.., FA..B, FH..B, FV..B:

Gear units	Fill quantity in liters					
	M1	M2	M3	M4	M5	M6
<b>F..27</b>	0.6	0.8	0.7	0.7	0.6	0.6
<b>F..37</b>	1	1.2	0.7	1.2	1	1.1
<b>F..47</b>	1.5	1.8	1.1	1.9	1.5	1.7
<b>F..57</b>	2.6	3.7	2.1	3.5	2.8	2.9
<b>F..67</b>	2.7	3.8	1.9	3.8	2.9	3.2
<b>F..77</b>	5	7.3	4.3	8	6	6.3
<b>F..87</b>	10	13.0	7.7	13.8	10.8	11
<b>F..97</b>	18.5	22.5	12.6	25.2	18.5	20
<b>F..107</b>	24.5	32	19.5	37.5	27	27
<b>F..127</b>	40.5	55	34	61	46.5	47
<b>F..157</b>	69	104	63	105	86	78

FF..:

Gear units	Fill quantity in liters					
	M1	M2	M3	M4	M5	M6
<b>FF27</b>	0.6	0.8	0.7	0.7	0.6	0.6
<b>FF37</b>	1	1.2	0.7	1.3	1	1.1
<b>FF47</b>	1.6	1.9	1.1	1.9	1.5	1.7
<b>FF57</b>	2.8	3.8	2.1	3.7	2.9	3
<b>FF67</b>	2.7	3.8	1.9	3.8	2.9	3.2
<b>FF77</b>	5.1	7.3	4.3	8.1	6	6.3
<b>FF87</b>	10.3	13.2	7.8	14.1	11	11.2
<b>FF97</b>	19	22.5	12.6	25.5	18.9	20.5
<b>FF107</b>	25.5	32	19.5	38.5	27.5	28
<b>FF127</b>	41.5	56	34	63	46.5	49
<b>FF157</b>	72	105	64	106	87	79

FA.., FH.., FV.., FAF.., FHF.., FVF.., FAZ.., FHZ.., FVZ..:

Gear units	Fill quantity in liters					
	M1	M2	M3	M4	M5	M6
<b>F..27</b>	0.6	0.8	0.7	0.7	0.6	0.6
<b>F..37</b>	1	1.2	0.7	1.2	1	1.1
<b>F..47</b>	1.5	1.8	1.1	1.9	1.5	1.7
<b>F..57</b>	2.7	3.8	2.1	3.6	2.9	3
<b>F..67</b>	2.7	3.8	1.9	3.8	2.9	3.2
<b>F..77</b>	5	7.3	4.3	8	6	6.3
<b>F..87</b>	10	13.0	7.7	13.8	10.8	11
<b>F..97</b>	18.5	22.5	12.6	25.0	18.5	20
<b>F..107</b>	24.5	32	19.5	37.5	27	27
<b>F..127</b>	39	55	34	61	45	46.5
<b>F..157</b>	68	103	62	104	85	77



Helical-bevel (K-)  
gear units

K.., KA..B, KH..B, KV..B:

Gear units	Fill quantity in liters					
	M1	M2	M3	M4	M5	M6
K..37	0.5	1	1	1.3	1	1
K..47	0.8	1.3	1.5	2	1.6	1.6
K..57	1.2	2.3	2.5	3	2.6	2.4
K..67	1.1	2.4	2.6	3.4	2.6	2.6
K..77	2.2	4.1	4.4	5.9	4.2	4.4
K..87	3.7	8	8.7	10.9	7.8	8
K..97	7	14	15.7	20	15.7	15.5
K..107	10	21	25.5	33.5	24	24
K..127	21	41.5	44	54	40	41
K..157	31	62	65	90	58	62
K..167	35	100	100	125	85	85
K..187	60	170	170	205	130	130

KF..:

Gear units	Fill quantity in liters					
	M1	M2	M3	M4	M5	M6
KF37	0.5	1.1	1.1	1.5	1	1
KF47	0.8	1.3	1.7	2.2	1.6	1.6
KF57	1.3	2.3	2.7	3	2.9	2.7
KF67	1.1	2.4	2.8	3.6	2.7	2.7
KF77	2.1	4.1	4.4	6	4.5	4.5
KF87	3.7	8.2	9	11.9	8.4	8.4
KF97	7	14.7	17.3	21.5	15.7	16.5
KF107	10	22	26	35	25	25
KF127	21	41.5	46	55	41	41
KF157	31	66	69	92	62	62

KA.., KH.., KV.., KAF.., KHF.., KVF.., KAZ.., KHZ.., KVZ..:

Gear units	Fill quantity in liters					
	M1	M2	M3	M4	M5	M6
K..37	0.5	1	1	1.4	1	1
K..47	0.8	1.3	1.6	2.1	1.6	1.6
K..57	1.3	2.3	2.7	3	2.9	2.7
K..67	1.1	2.4	2.7	3.6	2.6	2.6
K..77	2.1	4.1	4.6	6	4.4	4.4
K..87	3.7	8.2	8.8	11.1	8	8
K..97	7	14.7	15.7	20	15.7	15.7
K..107	10	20.5	24	32	24	24
K..127	21	41.5	43	52	40	40
K..157	31	66	67	87	62	62
KH167	35	100	100	125	85	85
KH187	60	170	170	205	130	130



### *Spiroplan® (W-) gear units*

The Spiroplan® gear units always have the same fill quantity, independent of the mounting position:

Gear units	Mounting position independent fill quantity in liters
W..10	0.16
W..20	0.26
W..30	0.5

### *Helical-worm (S-) gear units*

S...:

Gear units	Fill quantity in liters					
	M1	M2	M3 <sup>1)</sup>	M4	M5	M6
S37	0.25	0.4	0.5	0.6	0.4	0.4
S47	0.35	0.8	0.7/0.9	1.1	0.8	0.8
S57	0.5	1.2	1/1.2	1.5	1.3	1.3
S67	1	2.0	2.2/3.1	3.2	2.6	2.6
S77	1.9	4.2	3.7/5.4	6	4.4	4.4
S87	3.3	8.1	6.9/10.4	12	8.4	8.4
S97	6.8	15	13.4/18	22.5	17	17

1) The larger gear unit in multi-stage gear units must be filled with the larger oil quantity.

SF...:

Gear units	Fill quantity in liters					
	M1	M2	M3 <sup>1)</sup>	M4	M5	M6
SF37	0.25	0.4	0.5	0.6	0.4	0.4
SF47	0.4	0.9	0.9/1.1	1.2	1.0	1
SF57	0.5	1.2	1/1.5	1.6	1.4	1.4
SF67	1	2.2	2.3/3	3.2	2.7	2.7
SF77	1.9	4.1	3.9/5.8	6.5	4.9	4.9
SF87	3.8	8	7.1/10.1	12	9.1	9.1
SF97	7.4	15	13.8/18.8	23.6	18	18

1) The larger gear unit in multi-stage gear units must be filled with the larger oil quantity.

SA..., SH..., SAF..., SHF..., SAZ..., SHZ...:

Gear units	Fill quantity in liters					
	M1	M2	M3 <sup>1)</sup>	M4	M5	M6
S..37	0.25	0.4	0.5	0.6	0.4	0.4
S..47	0.4	0.8	0.7/0.9	1.1	0.8	0.8
S..57	0.5	1.1	1/1.5	1.6	1.2	1.2
S..67	1	2	1.8/2.6	2.9	2.5	2.5
S..77	1.8	3.9	3.6/5	5.9	4.5	4.5
S..87	3.8	7.4	6/8.7	11.2	8	8
S..97	7	14	11.4/16	21	15.7	15.7

1) The larger gear unit in multi-stage gear units must be filled with the larger oil quantity.



## Address list

### Addresses

Germany			
<b>Headquarters Production Sales Service</b>	<b>Bruchsal</b>	SEW-EURODRIVE GmbH & Co Ernst-Blickle-Straße 42 D-76646 Bruchsal P.O. Box Postfach 3023 · D-76642 Bruchsal	Tel. (0 72 51) 75-0 Fax (0 72 51) 75-19 70 <a href="http://www.SEW-EURODRIVE.de">http://www.SEW-EURODRIVE.de</a> <a href="mailto:sew@sew-eurodrive.de">sew@sew-eurodrive.de</a>
<b>Production</b>	<b>Graben</b>	SEW-EURODRIVE GmbH & Co Ernst-Blickle-Straße 1 D-76676 Graben-Neudorf P.O. Box Postfach 1220 · D-76671 Graben-Neudorf	Tel. (0 72 51) 75-0 Fax (0 72 51) 75-29 70 Telex 7 822 276
<b>Assembly Service</b>	<b>Garbsen</b> (near Hannover)	SEW-EURODRIVE GmbH & Co Alte Ricklinger Straße 40-42 D-30823 Garbsen P.O. Box Postfach 110453 · D-30804 Garbsen	Tel. (0 51 37) 87 98-30 Fax (0 51 37) 87 98-55
	<b>Kirchheim</b> (near München)	SEW-EURODRIVE GmbH & Co Domagkstraße 5 D-85551 Kirchheim	Tel. (0 89) 90 95 52-10 Fax (0 89) 90 95 52-50
	<b>Langenfeld</b> (near Düsseldorf)	SEW-EURODRIVE GmbH & Co Siemensstraße 1 D-40764 Langenfeld	Tel. (0 21 73) 85 07-30 Fax (0 21 73) 85 07-55
	<b>Meerane</b> (near Zwickau)	SEW-EURODRIVE GmbH & Co Dänkritzer Weg 1 D-08393 Meerane	Tel. (0 37 64) 76 06-0 Fax (0 37 64) 76 06-30
	Additional addresses for service in Germany provided on request!		
France			
<b>Production Sales Service</b>	<b>Hagenau</b>	SEW-USOCOME SAS 48-54, route de Soufflenheim B. P. 185 F-67506 Hagenau Cedex	Tel. 03 88 73 67 00 Fax 03 88 73 66 00 <a href="http://www.usocome.com">http://www.usocome.com</a> <a href="mailto:sew@usocome.com">sew@usocome.com</a>
<b>Assembly Sales Service</b>	<b>Bordeaux</b>	SEW-USOCOME SAS Parc d'activités de Magellan 62, avenue de Magellan - B. P. 182 F-33607 Pessac Cedex	Tel. 05 57 26 39 00 Fax 05 57 26 39 09
	<b>Lyon</b>	SEW-USOCOME SAS Parc d'Affaires Roosevelt Rue Jacques Tati F-69120 Vaulx en Velin	Tel. 04 72 15 37 00 Fax 04 72 15 37 15
	<b>Paris</b>	SEW-USOCOME SAS Zone industrielle 2, rue Denis Papin F-77390 Verneuil l'Etang	Tel. 01 64 42 40 80 Fax 01 64 42 40 88
	Additional addresses for service in France provided on request!		
Argentina			
<b>Assembly Sales Service</b>	<b>Buenos Aires</b>	SEW EURODRIVE ARGENTINA S.A. Centro Industrial Garin, Lote 35 Ruta Panamericana Km 37,5 1619 Garin	Tel. (3327) 45 72 84 Fax (3327) 45 72 21 <a href="mailto:sewar@sew-eurodrive.com.ar">sewar@sew-eurodrive.com.ar</a>
Australia			
<b>Assembly Sales Service</b>	<b>Melbourne</b>	SEW-EURODRIVE PTY. LTD. 27 Beverage Drive Tullamarine, Victoria 3043	Tel. (03) 99 33 10 00 Fax (03) 99 33 10 03
	<b>Sydney</b>	SEW-EURODRIVE PTY. LTD. 9, Sleigh Place, Wetherill Park New South Wales, 2164	Tel. (02) 97 25 99 00 Fax (02) 97 25 99 05
Austria			
<b>Assembly Sales Service</b>	<b>Wien</b>	SEW-EURODRIVE Ges.m.b.H. Richard-Strauss-Strasse 24 A-1230 Wien	Tel. (01) 6 17 55 00-0 Fax (01) 6 17 55 00-30 <a href="mailto:sew@sew-eurodrive.at">sew@sew-eurodrive.at</a>



<b>Belgium</b>			
<b>Assembly Sales Service</b>	<b>Brüssel</b>	CARON-VECTOR S.A. Avenue Eiffel 5 B-1300 Wavre	Tel. (010) 23 13 11 Fax (010) 2313 36 <a href="http://www.caron-vector.be">http://www.caron-vector.be</a> <a href="mailto:info@caron-vector.be">info@caron-vector.be</a>
<b>Brazil</b>			
<b>Production Sales Service</b>	<b>Sao Paulo</b>	SEW DO BRASIL Motores-Redutores Ltda. Rodovia Presidente Dutra, km 208 CEP 07210-000 - Guarulhos - SP	Tel. (011) 64 60-64 33 Fax (011) 64 80 33 28 <a href="mailto:sew@sew.com.br">sew@sew.com.br</a>
Additional addresses for service in Brazil provided on request!			
<b>Bulgaria</b>			
<b>Sales</b>	<b>Sofia</b>	BEVER-DRIVE GMBH Bogdanovetz Str.1 BG-1606 Sofia	Tel. (92) 9 53 25 65 Fax (92) 9 54 93 45 <a href="mailto:bever@mbbox.infotel.bg">bever@mbbox.infotel.bg</a>
<b>Canada</b>			
<b>Assembly Sales Service</b>	<b>Toronto</b>	SEW-EURODRIVE CO. OF CANADA LTD. 210 Walker Drive Bramalea, Ontario L6T3W1	Tel. (905) 7 91-15 53 Fax (905) 7 91-29 99
	<b>Vancouver</b>	SEW-EURODRIVE CO. OF CANADA LTD. 7188 Honeyman Street Delta. B.C. V4G 1 E2	Tel. (604) 9 46-55 35 Fax (604) 946-2513
	<b>Montreal</b>	SEW-EURODRIVE CO. OF CANADA LTD. 2555 Rue Leger Street LaSalle, Quebec H8N 2V9	Tel. (514) 3 67-11 24 Fax (514) 3 67-36 77
Additional addresses for service in Canada provided on request!			
<b>Chile</b>			
<b>Assembly Sales Service</b>	<b>Santiago de Chile</b>	SEW-EURODRIVE CHILE Motores-Reductores LTDA. Panamericana Norte No 9261 Casilla 23 - Correo Quilicura RCH-Santiago de Chile	Tel. (02) 6 23 82 03+6 23 81 63 Fax (02) 6 23 81 79
<b>China</b>			
<b>Production Assembly Sales Service</b>	<b>Tianjin</b>	SEW-EURODRIVE (Tianjin) Co., Ltd. No. 46, 7th Avenue, TEDA Tianjin 300457	Tel. (022) 25 32 26 12 Fax (022) 25 32 26 11
<b>Colombia</b>			
<b>Assembly Sales Service</b>	<b>Bogotá</b>	SEW-EURODRIVE COLOMBIA LTDA. Calle 22 No. 132-60 Bodega 6, Manzana B Santafé de Bogotá	Tel. (0571) 5 47 50 50 Fax (0571) 5 47 50 44 <a href="mailto:sewcol@andinet.com">sewcol@andinet.com</a>
<b>Croatia</b>			
<b>Sales Service</b>	<b>Zagreb</b>	KOMPEKS d. o. o. PIT Erdödy 4 II HR 10 000 Zagreb	Tel. +385 14 61 31 58 Fax +385 14 61 31 58
<b>Czech Republic</b>			
<b>Sales</b>	<b>Praha</b>	SEW-EURODRIVE S.R.O. Business Centrum Praha Luná 591 16000 Praha 6	Tel. 02/20 12 12 34 + 20 12 12 36 Fax 02/20 12 12 37 <a href="mailto:sew@sew-eurodrive.cz">sew@sew-eurodrive.cz</a>
<b>Denmark</b>			
<b>Assembly Sales Service</b>	<b>Kopenhagen</b>	SEW-EURODRIVE A/S Geminivej 28-30, P.O. Box 100 DK-2670 Greve	Tel. 4395 8500 Fax 4395 8509 <a href="http://www.sew-eurodrive.dk">http://www.sew-eurodrive.dk</a> <a href="mailto:sew@sew-eurodrive.dk">sew@sew-eurodrive.dk</a>
<b>Estonia</b>			
<b>Sales</b>	<b>Tallin</b>	ALAS-KUUL AS Paldiski mnt.125 EE 0006 Tallin	Tel. 6 59 32 30 Fax 6 59 32 31



## Address list

<b>Finland</b>			
<b>Assembly Sales Service</b>	<b>Lahti</b>	SEW-EURODRIVE OY Vesimäentie 4 FIN-15860 Hollola 2	Tel. (3) 589 300 Fax (3) 780 6211
<b>Great Britain</b>			
<b>Assembly Sales Service</b>	<b>Normanton</b>	SEW-EURODRIVE Ltd. Beckbridge Industrial Estate P.O. Box No.1 GB-Normanton, West- Yorkshire WF6 1QR	Tel. 19 24 89 38 55 Fax 19 24 89 37 02
<b>Greece</b>			
<b>Sales Service</b>	<b>Athen</b>	Christ. Boznos & Son S.A. 12, Mavromichali Street P.O. Box 80136, GR-18545 Piraeus	Tel. 14 22 51 34 Fax 14 22 51 59 Boznos@otenet.gr
<b>Hong Kong</b>			
<b>Assembly Sales Service</b>	<b>Hong Kong</b>	SEW-EURODRIVE LTD. Unit No. 801-806, 8th Floor Hong Leong Industrial Complex No. 4, Wang Kwong Road Kowloon, Hong Kong	Tel. 2-7 96 04 77 + 79 60 46 54 Fax 2-7 95-91 29sew@sewhk.com
<b>Hungary</b>			
<b>Sales Service</b>	<b>Budapest</b>	SEW-EURODRIVE Kft. H-1037 Budapest Kunigunda u. 18	Tel. +36 1 437 06 58 Fax +36 1 437 06 50
<b>India</b>			
<b>Assembly Sales Service</b>	<b>Baroda</b>	SEW-EURODRIVE India Pvt. Ltd. Plot No. 4, Gidc Por Ramangamdi - Baroda - 391 243 Gujarat	Tel. 0 265-83 10 86 Fax 0 265-83 10 87 sew.baroda@gecs.com
<b>Ireland</b>			
<b>Sales Service</b>	<b>Dublin</b>	Alpert Engineering Ltd. 48 Moyle Road Dublin Industrial Estate Glasnevin, Dublin 11	Tel. (01) 8 30 62 77 Fax (01) 8 30 64 58
<b>Italy</b>			
<b>Assembly Sales Service</b>	<b>Milano</b>	SEW-EURODRIVE di R. Blicke & Co.s.a.s. Via Bernini,14 I-20020 Solaro (Milano)	Tel. (02) 96 98 01 Fax (02) 96 79 97 81
<b>Japan</b>			
<b>Assembly Sales Service</b>	<b>Toyoda-cho</b>	SEW-EURODRIVE JAPAN CO., LTD 250-1, Shimoman-no, Toyoda-cho, Iwata gun Shizuoka prefecture, P.O. Box 438-0818	Tel. (0 53 83) 7 3811-13 Fax (0 53 83) 7 3814
<b>Korea</b>			
<b>Assembly Sales Service</b>	<b>Ansan-City</b>	SEW-EURODRIVE KOREA CO., LTD. B 601-4, Banweol Industrial Estate Unit 1048-4, Shingil-Dong Ansan 425-120	Tel. (031) 4 92-80 51 Fax (031) 4 92-80 56
<b>Luxembourg</b>			
<b>Assembly Sales Service</b>	<b>Brüssel</b>	CARON-VECTOR S.A. Avenue Eiffel 5 B-1300 Wavre	Tel. (010) 23 13 11 Fax (010) 2313 36 <a href="http://www.caron-vector.be">http://www.caron-vector.be</a> info@caron-vector.be
<b>Macedonia</b>			
<b>Sales</b>	<b>Skopje</b>	SGS-Skopje / Macedonia "Teodosij Sinactski" 6691000 Skopje / Macedonia	Tel. (0991) 38 43 90 Fax (0991) 38 43 90
<b>Malaysia</b>			
<b>Assembly Sales Service</b>	<b>Johore</b>	SEW-EURODRIVE SDN BHD No. 95, Jalan Seroja 39, Taman Johor Jaya 81000 Johor Bahru, Johor West Malaysia	Tel. (07) 3 54 57 07 + 3 54 94 09 Fax (07) 3 5414 04





<b>Netherlands</b>			
<b>Assembly Sales Service</b>	<b>Rotterdam</b>	VECTOR Aandrijftechniek B.V. Industrieweg 175 NL-3044 AS Rotterdam Postbus 10085 NL-3004 AB Rotterdam	Tel. +31 10 44 63 700 Fax +31 10 41 55 552 <a href="http://www.vector.nu">http://www.vector.nu</a> <a href="mailto:info@vector.nu">info@vector.nu</a>
<b>New Zealand</b>			
<b>Assembly Sales Service</b>	<b>Auckland</b>	SEW-EURODRIVE NEW ZEALAND LTD. P.O. Box 58-428 82 Greenmount drive East Tamaki Auckland	Tel. 0064-9-2 74 56 27 Fax 0064-9-2 74 01 65 <a href="mailto:sales@sew-eurodrive.co.nz">sales@sew-eurodrive.co.nz</a>
	<b>Christchurch</b>	SEW-EURODRIVE NEW ZEALAND LTD. 10 Settlers Crescent, Ferrymead Christchurch	Tel. (09) 3 84 62 51 Fax (09) 3 84 64 55 <a href="mailto:sales@sew-eurodrive.co.nz">sales@sew-eurodrive.co.nz</a>
<b>Norway</b>			
<b>Assembly Sales Service</b>	<b>Moss</b>	SEW-EURODRIVE A/S Solgaard skog 71 N-1599 Moss	Tel. (69) 2410 20 Fax (69) 2410 40 <a href="mailto:sew@sew-eurodrive.no">sew@sew-eurodrive.no</a>
<b>Peru</b>			
<b>Assembly Sales Service</b>	<b>Lima</b>	SEW DEL PERU MOTORES REDUCTORES S.A.C. Los Calderos # 120-124 Urbanizacion Industrial Vulcano, ATE, Lima	Tel. (511) 349-52 80 Fax (511) 349-30 02 <a href="mailto:sewperu@terra.com.pe">sewperu@terra.com.pe</a>
<b>Poland</b>			
<b>Sales</b>	<b>Lodz</b>	SEW-EURODRIVE Polska Sp.z.o.o. ul. Pojezierska 63 91-338 Lodz	Tel. (042) 6 16 22 00 Fax (042) 6 16 22 10 <a href="mailto:sew@sew-eurodrive.pl">sew@sew-eurodrive.pl</a>
<b>Portugal</b>			
<b>Assembly Sales Service</b>	<b>Coimbra</b>	SEW-EURODRIVE, LDA. Apartado 15 P-3050-901 Mealhada	Tel. (0231) 20 96 70 Fax (0231) 20 36 85 <a href="mailto:infosew@sew-eurodrive.pt">infosew@sew-eurodrive.pt</a>
<b>Romania</b>			
<b>Sales Service</b>	<b>Bucuresti</b>	Sialco Trading SRL str. Madrid nr.4 71222 Bucuresti	Tel. (01) 2 30 13 28 Fax (01) 2 30 71 70 <a href="mailto:sialco@mediasat.ro">sialco@mediasat.ro</a>
<b>Russia</b>			
<b>Sales</b>	<b>St. Petersburg</b>	ZAO SEW-EURODRIVE P.O. Box 193 193015 St. Petersburg	Tel. (812) 3 26 09 41 + 5 35 04 30 Fax (812) 5 35 22 87 <a href="mailto:sewrus@post.spbnit.ru">sewrus@post.spbnit.ru</a>
<b>Singapore</b>			
<b>Assembly Sales Service</b>		SEW-EURODRIVE PTE. LTD. No 9, Tuas Drive 2 Jurong Industrial Estate Singapore 638644	Tel. 8 62 17 01-705 Fax 8 61 28 27 Telex 38 659
<b>Slovenia</b>			
<b>Sales Service</b>	<b>Celje</b>	Pakman - Pogonska Tehnika d.o.o. Ul. XIV. divizije 14 SLO – 3000 Celje	Tel. 00386 3 490 83 20 Fax 00386 3 490 83 21 <a href="mailto:pakman@siol.net">pakman@siol.net</a>



## Address list

South Africa			
Assembly Sales Service	<b>Johannesburg</b>	SEW-EURODRIVE (PROPRIETARY) LIMITED Eurodrive House Cnr. Adcock Ingram and Aerodrome Roads Aeroton Ext. 2 Johannesburg 2013 P.O.Box 90004 Bertsham 2013	Tel. + 27 11 248 70 00 Fax +27 11 494 23 11
	<b>Capetown</b>	SEW-EURODRIVE (PROPRIETARY) LIMITED Rainbow Park Cnr. Racecourse & Omuramba Road Montague Gardens Cape Town P.O.Box 36556 Chempet 7442 Cape Town	Tel. +27 21 552 98 20 Fax +27 21 552 98 30 Telex 576 062
	<b>Durban</b>	SEW-EURODRIVE (PROPRIETARY) LIMITED 2 Monaceo Place Pinetown Durban P.O. Box 10433, Ashwood 3605	Tel. +27 31 700 34 51 Fax +27 31 700 38 47
Spain			
Assembly Sales Service	<b>Bilbao</b>	SEW-EURODRIVE ESPAÑA, S.L. Parque Tecnológico, Edificio, 302 E-48170 Zamudio (Vizcaya)	Tel. 9 44 31 84 70 Fax 9 44 31 84 71 sew.spain@sew-eurodrive.es
Sweden			
Assembly Sales Service	<b>Jönköping</b>	SEW-EURODRIVE AB Gnejsvägen 6-8 S-55303 Jönköping Box 3100 S-55003 Jönköping	Tel. (036) 34 42 00 Fax (036) 34 42 80 www.sew-eurodrive.se
Switzerland			
Assembly Sales Service	<b>Basel</b>	Alfred Imhof A.G. Jurastrasse 10 CH-4142 Münchenstein bei Basel	Tel. (061) 4 17 17 17 Fax (061) 4 17 17 00 <a href="http://www.imhof-sew.ch">http://www.imhof-sew.ch</a> info@imhof-sew.ch
Thailand			
Assembly Sales Service	<b>Chon Buri</b>	SEW-EURODRIVE (Thailand) Ltd. Bangpakong Industrial Park 2 700/456, Moo.7, Tambol Donhuaroh Muang District Chon Buri 20000	Tel. 0066-38 21 40 22 Fax 0066-38 21 45 31
Turkey			
Assembly Sales Service	<b>Istanbul</b>	SEW-EURODRIVE Hareket Sistemleri San. ve Tic. Ltd. Sti Bagdat Cad. Koruma Cikmazi No. 3 TR-81540 Maltepe ISTANBUL	Tel. (0216) 4 41 91 63 + 4 41 91 64 + 3 83 80 14 + 3 83 80 15 Fax (0216) 3 05 58 67 seweurodrive@superonline.com.tr
USA			
Production Assembly Sales Service	<b>Greenville</b>	SEW-EURODRIVE INC. 1295 Old Spartanburg Highway P.O. Box 518 Lyman, S.C. 29365	Tel. (864) 4 39 75 37 Fax Sales (864) 439-78 30 Fax Manuf. (864) 4 39-99 48 Fax Ass. (864) 4 39-05 66 Telex 805 550
Assembly Sales Service	<b>San Francisco</b>	SEW-EURODRIVE INC. 30599 San Antonio St. Hayward, California 94544-7101	Tel. (510) 4 87-35 60 Fax (510) 4 87-63 81
	<b>Philadelphia/PA</b>	SEW-EURODRIVE INC. Pureland Ind. Complex 200 High Hill Road, P.O. Box 481 Bridgeport, New Jersey 08014	Tel. (856) 4 67-22 77 Fax (856) 8 45-31 79
	<b>Dayton</b>	SEW-EURODRIVE INC. 2001 West Main Street Troy, Ohio 45373	Tel. (9 37) 3 35-00 36 Fax (9 37) 4 40-37 99
	<b>Dallas</b>	SEW-EURODRIVE INC. 3950 Platinum Way Dallas, Texas 75237	Tel. (214) 3 30-48 24 Fax (214) 3 30-47 24






USA			
Additional addresses for service in the USA provided on request!			
Venezuela			
<b>Assembly Sales Service</b>	<b>Valencia</b>	SEW-EURODRIVE Venezuela S.A. Av. Norte Sur No. 3, Galpon 84-319 Zona Industrial Municipal Norte Valencia	Tel. +58 (241) 8 32 98 04 Fax +58 (241) 8 38 62 75 sewventas@cantr.net sewfinanzas@cantr.net


SEW-EURODRIVE GmbH & Co · P.O. Box 3023 · D-76642 Bruchsal/Germany · Phone +49-7251-75-0  
Fax +49-7251-75-1970 · <http://www.sew-eurodrive.com> · [sew@sew-eurodrive.com](mailto:sew@sew-eurodrive.com)



**SEW**  
**EURODRIVE**






REVISIONS	A: 05/05/99 ORIGINAL ISSUE 0000	DRAWN T.BERNARDI		WEB-TECH AUSTRALIA PTY. LTD. A.C.N. 010 764 431 11 ELECTRONICS STREET EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA P.O. BOX 4006 EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA Phone +61-7-3841 2844 Fax +61-7-3841 0005	SIZE A1	DRAWING No.	
	B: 15/09/00 FLEXURE WEIGHFRAME ADDED ECN: 0000					NUMBER 07350003	REV. B
	CUSTOMER						
	PROJECT						
	CAD FILE 07350003B						
		APPROVED	TITLE WT735 OPEN CONSTRUCTION WEIGHFEEDER BW = 300 I-D = 735 GENERAL ARRANGEMENT	ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED		This drawing and any information or descriptive matter set out hereon are the confidential and copyright property of WEB-TECH AUSTRALIA PTY. LTD. and must not be disclosed, loaned, copied or used for manufacturing / tendering or for any other purpose without their written permission.	
		DATE APP'D					
		SCALE 1:5					
		 DO NOT SCALE IF IN DOUBT ASK					



REVISIONS	A. 11/03/99 ORIGINAL ISSUE	CERTIFICATION WEB-TECH AUSTRALIA PTY. LTD. CUSTOMER No.: CUSTOMER ORDER No.:		UNLESS OTHERWISE STATED UNTOLERANCED DIMENSIONS TO BE WITHIN THE LIMITS SHOWN			DRAWN T.BERNARDI	 <b>WEB-TECH AUSTRALIA PTY. LTD.</b> A.C.N. 010 764 431 11 ELECTRONICS STREET EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA P.O. BOX 4006 EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA Phone +61-7-3841 2844 Fax +61-7-3841 0005	SIZE A1	DRAWING No.				
		<input type="checkbox"/> RETURN OF APPROVAL NOT REQUIRED <input type="checkbox"/> RETURN APPROVAL FOR RECORD <input type="checkbox"/> BEFORE MANUFACTURING PROCEEDS		NOMINAL SIZE	UP TO 50	ABOVE 50 UP TO 150	ABOVE 150 UP TO 300		ABOVE 300 UP TO 1000	CHECKED	NUMBER WTMW1	SHT. 02	REV. A	
		WEB-TECH AUSTRALIA PTY. LTD. CERTIFIED BY: DATE //		MACHINING	± 0.1	± 0.2	± 0.3		± 0.5	± 1.0	DATE APP'D	CONTRACT		
		CUSTOMER APPROVAL DATE //		FABRICATION	± 0.5	± 0.5	± 0.5		± 1.0	± 2.0	SCALE	PROJECT		
		<input type="checkbox"/> APPROVED FOR CONSTRUCTION <input type="checkbox"/> APPROVED AS NOTED <input type="checkbox"/> APPROVED AS NOTED - RESUBMIT		ASSEMBLIES	± 0.5	± 0.5	± 0.5		± 1.0	± 2.0	 DO NOT SCALE IF IN DOUBT ASK	CAD FILE WT05010A		
		TITLE ELECTRICAL CONNECTION DIAGRAM FOR WT735 ,1200 & 1700 WEIGHFEEDER SYSTEMS INCPOR MASTERWEIGH 1							ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED					
									This drawing and any information or descriptive matter set out herein are the confidential and copyright property of WEB-TECH AUSTRALIA PTY. LTD. (®) and must not be disclosed, loaned, copied or used for manufacturing / tendering or for any other purpose without their written permission.					






NOTES

REVISIONS  
A 20/02/96  
ORIGINAL ISSUE

UNLESS OTHERWISE STATED UNTOLERANCED DIMENSIONS TO BE WITHIN THE LIMITS SHOWN						DRAWN	M.W.
NOMINAL SIZE	UP TO 10	10 TO 30	30 TO 50	50 TO 100	100 TO 150	CHECKED	M.W.
FINISHING	±0.1	±0.2	±0.3	±0.5	±1.0	APPROVED	M.W.
FABRICATION	±0.5	±0.5	±0.5	±1.0	±2.0	DATE APP'D	18/06/2003
ASSEMBLY	±0.5	±0.5	±0.5	±1.0	±2.0	SCALE	N.T.S.
						DO NOT SCALE IF IN DOUBT ASK	

WEB-TECH AUSTRALIA PTY. LTD.				SIZE	DRAWING No.		
8 ELECTRONIC STREET UNIT 10/11 FLEMING, QUEENSLAND, 405, AUSTRALIA PO BOX 406 1200 FLEMING, QUEENSLAND, 405, AUSTRALIA Phone +61-7-5561 8801 Fax +61-7-5561 8802				A1	NUMBER	SHT.	REV.
					SMLCJB-02	1	B
				CONTRACT			
				PROJECT			
				CAB FILE			
				TITLE			
				MODEL 735 1200 AND 1700 WEIGHFEEDER LOADCELL JUNCTION BOX CONNECTION DIAGRAM			
				ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED			
				This drawing and any information or description written, and all herein are the confidential and proprietary property of WEB-TECH AUSTRALIA PTY. LTD. and shall not be copied, reproduced, stored in a retrieval system, or used for any other purpose without prior written permission.			



REVISIONS	A. 21/11/05 ORIGINAL ISSUE	DRAWN	L.HARTLEY	 <b>WEB-TECH AUSTRALIA PTY. LTD.</b> A.C.N. 010 764 431 11 ELECTRONICS STREET EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA P.O. BOX 4006 EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA Phone +61-7-3841 2844 Fax +61-7-3841 0005	SIZE	DRAWING No.	
		CHECKED	L.HARTLEY		A1	NUMBER	REV.
		APPROVED	L.HARTLEY			SSJBOX	A
		DATE APP'D	21/11/05			CUSTOMER	
		SCALE	N.T.S			PROJECT	
				DO NOT SCALE IF IN DOUBT ASK	CAD FILE SSJBOX		
					ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED		
			This drawing and any information or descriptive matter set out herein are the confidential and copyright property of WEB-TECH AUSTRALIA PTY. LTD. ® and must not be disclosed, loaned, copied or used for manufacturing / tendering or for any other purpose without their written permission.				



## WEB-TECH AUSTRALIA PTY LTD

Customer : \_\_\_\_\_ Conveyor Designation : \_\_\_\_\_

Material : \_\_\_\_\_ Model : \_\_\_\_\_ Date : \_\_\_\_\_

Load Cell Type : \_\_\_\_\_ Tacho : \_\_\_\_\_ Data By : \_\_\_\_\_

MW S/No : \_\_\_\_\_ Software Version : \_\_\_\_\_ Contract No : \_\_\_\_\_

Order No. \_\_\_\_\_

MENU	FUNCTION	MASTERWEIGH 1 SETTINGS
1	Parameter Setup	Capacity : _____ Increments Size: _____ Zero Reference : _____ mV Precision Reference : _____ mV Pulse Width: _____ ms
2	Pulses per Belt Revolution	Programmed Pulses per Belt Revolution : _____ No. of Belt Revs : _____
3	Zero Calibration	Zero Calibration : _____ mV AutoZero Tracking : _____ mV
4	Fixed Weight Calibrate	Span : _____ Target Weight : <b>#REF!</b> kgs
5	Emperical Span	Emperical Span : _____
6	Null Level	Null Level : _____
7	Auto Zero Tracking	Auto Zero Level : _____ Auto Zero Period : _____ Delay Time : _____ sec
8	Loadcell Input	Dynamic (No Load) : _____ mV Dynamic (with weights) : _____ mV
9	Tacho Frequency	Tacho Frequency : _____ Hz @ _____ Hz on VF Drive (if appl.)
10	High Alarm Setpoint	High Alarm Level : _____ Alarm Delay : _____ sec
11	Low Alarm Setpoint	Low Alarm Level : _____ Alarm Delay : _____ sec
12	Parameter Print	NOT USED
13	Auto/Manual Control of PID	Auto / Manual
14	PID Parameters	Current Setpoint : _____ Proportional Term : _____ Integral Term : _____ Integral Lower Limit : _____ Integral Upper Limit : _____ Differential Term : _____ O/P Offset Term : _____ Feed Forw. Term: _____
15	Remote Setpoint Mode	_____
16	Remote Setpoint	_____
17	Filter Constants	Display Time Constant : _____ secs Rate O/P Time Constant : _____ secs Cascade Time Constant : _____ secs PID I/P Time Constant : _____ secs PID O/P Time Constant : _____ secs
18	Displayed Units	_____
19	Belt Speed Indication	Indicated Belt Speed : _____ m/sec @ _____ Hz on VF Drive (if appl.) Current Belt Length : _____ metres

## WEB-TECH WEIGHFEEDER DESIGN DATA SHEET

**CLIENT :** \_\_\_\_\_ **DATE :** \_\_\_\_\_

**DESIGNATION :** \_\_\_\_\_ **MODEL** \_\_\_\_\_

**CALIBRATION METHOD : BAR(S) / CHAIN**

### **CALIBRATION BAR(S)**

1. CALIBRATION BAR QTY AND TOTAL WEIGHT \_\_\_\_\_ = \_\_\_\_\_
2. IDLER PITCH \_\_\_\_\_
3. TOTAL WEIGH AREA \_\_\_\_\_ metres
4. EQUIVALENT LOADING/M WITH CAL BAR(S) (Item 1 x 1/Item 3) = \_\_\_\_\_
5. BELT SPEED \_\_\_\_\_ m/s
6. SIMULATED MASS RATE (Item 4 x Item 5 x 3600 ) = \_\_\_\_\_ kg/hr
7. BELT LENGTH \_\_\_\_\_ metres
8. No. OF BELT REVOLUTIONS FOR TEST \_\_\_\_\_
9. **TARGET WEIGHT ( Item 4 x Item 7 x Item 8 ) =** \_\_\_\_\_ kgs

### **CALIBRATION CHAIN**

1. WEIGHT OF CALIBRATION CHAIN PER STRAND \_\_\_\_\_ kg/m
2. No. OF STRANDS \_\_\_\_\_
3. TOTAL WEIGHT OF CALIBRATION CHAIN (Item 1 x Item 2 ) \_\_\_\_\_ kg/m
4. BELT LENGTH \_\_\_\_\_ m
5. No. OF BELT REVOLUTIONS FOR TEST \_\_\_\_\_
4. **TARGET WEIGHT ( Item 3 x Item 4 x Item 5 ) =** \_\_\_\_\_ kgs